

SUBMITTAL	ITEM TYPE	TITLE	LAST UPDATED
STANDARD ITEM	FIRE ACCESS	TOMAR STROBE MODEL 1790-1014- SM2	May 1, 2014 3:17 PM



HOW IT WORKS:

THE EMERGENCY VEHICLE TRANSMITS A CONTINUOUSLY FLASHING OPTICAL SIGNAL TO THE TOMAR STROBE SWITCH. SIGNALS IN THE CORRECT FORMAT CAUSE THE TOMAR STROBE SWITCH TO ACTIVATE A RELAY. THE RELAY CONTACTS MAY BE WIRED TO CONTROL MANY DEVICES INCLUDING SECURITY GATES AND DOORS.



SPECS:

RANGE

200FT TYPICAL

FIELD OF VIEW

10DEG VERTICAL, 90DEG HORIZONTAL

SIGNAL ACQUISITION TIME

0.64 SECONDS

FUNCTION INDICATOR

RED LED ILLUMINATES WHEN SIGNAL IS RECEIVED
VISIBLE FROM 25'

FREQUENCY

F14= 14.035HZ +/- 0.25HZ (HIGH PRIORITY)

F10= 10.000HZ +/- 0.25HZ (LOW PRIORITY)

1790M-2 POWER MODULE

12-24VDC AC/DC

DPDT RELAY OUTPUT 2A @ 30VDC, 0.6A @ VAC

0-30 MIN TIME DELAY PLUS CONTINUOUS LATCH MODE
(REMOTE RESET OPTIONAL)

CODE COMPLIANCE

MANY FIRE DISTRICTS REQUIRE ACCESS TO A PROPERTY IN CASE OF AN EMERGENCY. THE TOMAR STROBE ALLOWS EMERGENCY VEHICLES AUTOMATIC ACCESS TO THE PROPERTY.



2525 NE COLUMBIA BLVD | PORTLAND, OR 97211
SERVICE 503.595.4716 | INSIDE SALES 503.946.1261 | TOLL FREE 1-888.813.6772

"SERVING THE PORTLAND/VANCOUVER METRO AREA SINCE 1984"