OPERATIONS MANAGER					FILTERED:	NO
#	Tool Name	Dia.	Rad.	Assembly	Holder	
1	1/2 FLAT ENDMILL	0.5	0.0		Default Holder	
2	3/8 BULL ENDMILL 0.0625 RAD	0.375	0.0625		Default Holder	
3	3/8 BALL ENDMILL	0.375	0.1875		Default Holder	
4	1/8 SPOTDRILL	0.125	0.0		Default Holder	