






Ensure your icon is correctly plotted to nearest city; click on your icon

NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M




Click on the notepad and review icon data on next screen



1. Ensure your data is correct.
2. If changes needed, go to
3 horizontal lines, settings,
my preferences


3. You can correct your icon
Location here



R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL
CE --- m LE --- m
Track: --- Kmph 357 ° M

Click this icon to measure distance and azimuth from your station to a station of your choosing


NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M



Click the point to measure range to.

Click on the station icon you want to measure

NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M




Click on the azimuth line

NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M


500 km
14Q PJ 54982 06403 --- ft MSL 1,123 km 176 ° M


5

TAK Network Status



1. Click on these two icons and see the changes you can make;
2. When done, click the trashcan to delete the range bearing





Click "measure"

NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M

13Q CD 99300 28678 --- ft MSL 1,379 km 216 ° M

5

TAK Network Status



Bloodhound



Dynamic Measure



Measure



Circle



Bullseye



Dead Reckoning

Range & Bearing

Click and drag to measure.

Click on the two points you want to measure

500 km

14Q LJ 32883 33054 --- ft MSL 1,135 km 193 ° M

5

TAK Network Status

NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M



Bloodhound



Dynamic Measure



Measure



Circle




Bullseye



Dead Reckoning

Range & Bearing




NO GPS

Callsign: R91 ALE 030 3G

14R PV 29268 28679

--- ft MSL 357 ° M




NO GPS

Callsign: R91 ALE 030 3G

14R PV 29268 28679

--- ft MSL 357° M








Click "Contacts"

NO GPS

Callsign: R91 ALE 030 3G

14R PV 29268 28679

--- ft MSL 357 ° M




Search for Desert Eagle and Click to open the dialogue box



- Contacts
- AAR3AV.3AVAAR.N...
 - AAR3EZ.MARS
 - AAR4BI.MARS.0006,...
 - AAR4EK.M012
 - AAR5AM.MARS ALE...
 - AAR5JD MARS 2GA...
 - AAR8GZ.MARS:8GZ...
 - AAR9PG_MARS_681...
 - AAT5AK
 - AAT6OB.MARS
 - AFA3ZV AFMARS
 - AFA5KK.MARS
 - AFA6HW.MARS
 - AFA6OC.MARS(cell)
 - DesertEagle 3G:038...
 - ORANGEMAIN
 - Paul.Decker.MARS
 - Q088
 - Rory.Griffin.MARS

NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M



In the dialogue box, insert the information as shown. Click "send" when complete

Individual MARS Callsign/# stations within circle/DTG (Z)
Ex: "AAR6PG/4/211756Z May 2024"

Contacts

DESERT Eagle

← ↗

SEND

RGR	@LCC	@VDO	@Brch	Mode
DZ	HLZ	nPos	Sec	DFLT

NO GPS
Callsign: R91 ALE 030 3G
14R PV 29268 28679
--- ft MSL 357 ° M