/mux7to1/SW	0001010101	0011010101	0101010101	1001010101	0000101010	0010101010	0100101010	1000101010
ux7to1/LEDR	zzzzzzzz1	zzzzzzzzz0	zzzzzzzzz1		zzzzzzzzz0	zzzzzzzzz1	zzzzzzzzz0	
mux7to1/data	1010101				0101010			
[6]								
[5]								
[4]								
[3]								
[2]								
[1]								
[0]								
/mux7to1/sel	000	001	010	100	000	001	010	100
[2]								
[1]								
[0]								
/mux7to1/out								
	ns	1	20 ns	30 ns			_	70 ns 80