Topic of Injector Design

Created by Unknown User (ahodge@mit.edu), last modified by Amir J White on Jul 07, 2022 18:22

Return to Learning Curriculum

LS6: Injector Design

Lecture Zoom Recording

Original Authors: John Posada '24, jposada@mit.edu & Max Kwon '22, mawkwon@mit.edu

- Note: This LSET is pretty long so check the summary at the bottom of this page if you'd prefer an abridged version
- . Great links (for the giga-nerds)
 - General resources
 - Wikipedia
 - Pyralis cold flow test (shoutout to our ancestors)
 - More advanced resources -- skip for now
 - Huzel & Huang the bread and butter of liquid prop
 - 4.5 Injector Design
 - That one NASA paper
 - 2.1 Injector Flow-System Geometry
 - But particularly 2.1.1.1 Total Element Pattern
 - Rocket propulsion elements textbook
 - This paper on pintle injectors
 - We use a pintle injector on the upcoming Romulus engine if you'd like to learn more!

What is an Injector?

The injector is a critical part of a liquid rocket engine (abbr. LRE) that is located between the upstream feed system and the combustion chamber. It is designed to **inject the propellants (fuel/ox) from the feed system into the combustion chamber** in a way that ensures three main things for the engine:


- 1. It optimizes the flow and the impingement of the propellants for optimal combustion
 - a. Optimal flow → better fuel efficiency (less uncombusted propellant)
 - b. Optimal combustion → better engine performance (more thrust)
- 2. It ensures that the combustion is stable for the entire time the engine is fired
- 3. It helps preserve the structural integrity of the combustion chamber and the engine itself
 - a. Mostly by ensuring that the resulting combustion temperature does not melt the chamber walls

Piping the propellants directly into the combustion chamber without a proper injector would be disastrous for the engine's mission because none of these points above would be satisfied.


You can think of the injector as the *interface* between the feed system, which supplies the propellants at certain mass flow rates, pressures, etc; and the combustion chamber, which requires certain performance metrics, pressures, temperatures, etc.

Below is a diagram of the design for the Helios injection system:





This design, unlike the doublet impinging jet design (discussed later), is relatively simple: it simply angles the fuel and oxidizer streams towards each other and slams them together really fast. Below is an image of the actual Helios injector (from a top-down view, as if you are the feed system):



The inner circle and outer ring groove are known as *manifolds* (discussed later), and the two sets of orifices for the propellants are seen in either of these manifolds. The outermost ring of large holes is just the bolt holes for securing the injector onto the engine.

The magic in the design is the precise hole diameters, angles, and lengths that ensure optimal flow behavior during firing. In addition, more considerations, like which propellant to inject through the centermost manifold, the shape of the manifold, and the number of orifices are very important in the design of this kind of injector. This video shows a cold flow test (water-only) of another style of an impinging jet design.

For those familiar with liquid engines in other types of vehicles, you'll know that many mix the propellants before combusting them in order to optimize the combustion. In many general aviation aircraft engines and older car engines, you'll find this premixer is the carburetor. In contrast, premixing in liquid rocket engines is usually not advisable because of the volatility of the propellants, and so ensuring optimal mixing inside the combustion chamber is also a task for the injector. However, do note that in some advanced rocket engines (like SpaceX's Raptor!), premixing before entering the combustion chamber is a thing that can be done.

Injector Performance

Before we get into the more specific aspects of injector design, it would be good to first understand what principles and metrics we're trying to satisfy with the injector. Also, throughout the design process, you'll often want to assess how 'good' your injector actually is at doing its job. But how do we evaluate this?

There are a few general metrics and areas that we should always take into consideration to try and evaluate both whether our design does

relatively well and whether the design will work within the rest of our engine's physical constraints. Of course, there will typically be even more metrics used in the research literature for different injector designs, which should also be considered but are not covered here.

We're going to mention these words a lot in this LSET. **Mixing** refers to the actual mixing of the different propellants into a local solution. The better 2 propellants mix, the better they can chemically react when they combust. **Atomization** refers to the breakup of a flowing propellant stream into individual droplets. This is important because smaller droplets both promote mixing (by allowing space for the other propellant to mix), and vaporization (since it's energetically easier for a droplet to convert to vapor than an entire stream of fluid).


Droplet Size

This is the 'measurable version' of atomization, and a metric we try to minimize. In practice, this is a very difficult thing to actually measure since you'd have to capture images inside the combustion chamber during injection, and because the droplet sizes differ over time, between propellants, and within a single propellant. For the metric, what we do is use one of a number of measurements that tries to capture the 'average droplet size'. A popular choice among them is the Sauter mean diameter (search it up if you're curious but don't think too hard about it).

But how would we find it, anyway? In some cases, we can estimate the droplet size using published empirical formulas (based on the chosen injector design/flow characteristics). We can also use computational fluid dynamics methods (abbr. **CFD**) to computationally model the flow and estimate it that way. CFD is a little difficult to learn and use properly, though, but it is a very popular tool for verifying flow characteristics.

Impingement Distance

The impingement distance can be defined as the axial distance the propellant travels before impinging with the other propellant. This is an important metric because it tells you at about what point in the combustion chamber you can expect most mixing to begin, and subsequently, a general idea of after where combustion will happen, which is good to know for thermal analysis and making sure your injector doesn't melt.



There's no real desire to have it very close to the injector (which can unnecessarily heat the faceplate) or to have it very far from the injector (which means your combustion chamber will have to be even longer). There are some rules of thumb found in the literature for what impingement distance you should aim for based on your injector type, and they are usually measured relative to the diameter of the orifices in the injector.

Vaporization Length

For the most part, the actual combustion inside an LRE occurs in the gas phase, which is why we want our liquid propellants to mix well before they vaporize so that they can combust more efficiently. The term **vaporization** simply refers to this conversion from liquid to gas in the propellants as they heat up inside the combustion chamber.

Vaporization length is a rough estimate of how far it'll take either propellant to travel within the chamber before they vaporize (and thus do the bulk of their combustion). Like droplet sizes, the most that can typically be done is to use a published empirical formula to try and find the vaporization length, then verify this using CFD.

Combustion Stability

This is quite a deep and pretty complex subject that has so much to cover, so we only give a general gist of it here. While the rocket engine is being fired, there are always unavoidable and pretty random chamber pressure fluctuations. If your entire system is designed well, these fluctuations appear just like low magnitude random noise and don't cause a problem. Typically, up to a 5% fluctuation in chamber

pressure is permissible (peak to peak pressure), but there are some cases where this threshold must be reduced further.

However, if these pressure fluctuations exhibit a different kind of behavior, it can be disastrous for your system. One common occurrence in

We bring this up because the injector is one of the most influential parts of a rocket engine when it comes to the stability of combustion. We won't cover here specifically how, but know that the design, and particularly the orifice pattern, of the injector plays an important role in stability, but can come at the price of having to compromise combustion performance and efficiency. In addition, there are some physical structures that can be added to the injector that can help mitigate combustion instabilities (namely baffles and acoustic cavities), but we won't cover those here.


Common Injector Types

Of course, there is not a single injector design that is best for any liquid rocket engine. Choosing which injection scheme to use depends on the objectives of the mission, experience of the design team, machining limitations, and other factors that must all be considered by the team before beginning development.

Here we cover 3 common types of designs used in liquid rocket engines, but there are many other types and variations to these that can be developed depending on what is needed for the engine.

Non-impinging Shower Head

Just kidding – before we get into designs that are used today, here's a design that is actually no longer used at all (because history is cool). It simply injects the propellants axially straight into the combustion chamber.



This design was used in the German V-2 rocket and relies on turbulence and the propellants diffusing in order to achieve proper mixing and combustion. It is the simplest non-impinging design but is no longer used because it requires a very large combustion chamber volume to work properly, and other designs are simply better. The following designs are currently widely used in liquid rocket engines.

Impinging Jet


Perhaps the simplest of these, the impinging jet design is simply sets of angled orifices that slam the two propellants together really fast (known as impinging them).

For these, there are considerations like hole diameters, angles, lengths, number of holes, spacing of holes, etc. It is very important to know the point and angles of impingement so that you can make sure you're not combusting directly onto the chamber wall and melting it.


The primary advantage of this design is its simplicity, which speeds up the design process considerably, and allows the team to machine the injector relatively quickly.

Like/Unlike Impinging Jet

For this design, you can choose to either impinge two *like* propellants (fuel on fuel, oxidizer on oxidizer) or two *unlike* propellants (fuel on oxidizer).




<u>Unline impinging jets</u> allow the two propellants to <u>mix very well</u>. As a note, unlike impinging jet designs are quite popular when the oxidizer is liquid oxygen (LOX), but the tradeoff is that it is relatively less stable than other common injector designs, and so combustion stability becomes a design concern.



Doublets/Triplets/etc.


It may also be beneficial to increase the number of streams impinging at a single point from 2 to 3 or more.




This design can help when there is a mismatch in the fuel and oxidizer stream momentums, which may result in an unfavorable resultant angle (e.g. that could spray flames towards the chamber wall instead of the nozzle exit). Additionally, increasing the amount/momentum of propellant impinging generally also improves the mixing of the propellants.

Pintle

The pintle injector design typically consists of just one element and works by impinging a central radial flow with an outer axial flow as shown below.




The injector gets its name from the pintle-shaped bit (that green knob thing on the far right of the figure below) that allows the central flow (the red below) to turn from going towards the nozzle exit to spraying radially, more towards the chamber walls. It then impinges directly onto the outer flow (the blue below) which is going axially down the chamber. The result of their combined flow is a cone of liquid film.



The pintle injector is a popular injector choice because it's not incredibly complex, and provides a few notable advantages:

- Improved mixing caused by the very sharp angle of impingement, and non-planar impingement area
- Lots of freedom in design choices namely, it's relatively easy to introduce orifices whose opening area can be changed allows the engine to be throttled (changing how much propellant we are injecting, which allows us to control thrust output)
- There has been observed combustion stability inherent to the pintle design

A few theories exist to explain this inherent combustion stability, but it is most likely due to two things: the pintle's central position in the chamber, and its **recirculation zones**. These <u>recirculation zones are an important characteristic of pintle injectors</u> and are where uncombusted propellants form (their own respective) loops in the chamber. Here, they deflect the incoming flow, and depending on the thermal profile, can either heat or cool the pintle tip and the chamber walls (it's kinda complicated!).




The first theory explains that the central pintle is located at a nodal point within the chamber's acoustic pressure field (you don't need to know what this means!), and so energy released at the pintle tip doesn't contribute very much to the pressure fluctuations that cause combustion instabilities. The second theory suggests that the recirculation zones act as a sort of 'damping zone' for possible instabilities arising from the combustion gases.

Of course, no design has only advantages. The pintle injector design can be susceptible to undesirable heating both on the pintle tip itself and on the chamber walls. As such, the pintle injector is often complemented by a dedicated cooling system (like regenerative cooling or film cooling!).

Coaxial Swirl

The coaxial swirl injector, as the name suggests, uses two coaxial tubes (called swirlers) that swirl their propellants. Once either propellant exits its swirler, it sprays into a cone of liquid film. Depending on the desired behavior, the cones can be made to collide with each other before reaching the chamber wall or not. Check out this video to see a cold flow test of a coaxial swirl injector.



The primary advantages of a coaxial swirl design are:

- Relatively stable across a large range of mass flow rates, allowing for higher mass flow rates than other designs
 - This is because the mixing and atomization processes that occur in the chamber are less sensitive to any pressure fluctuations
 or flow velocity variations with this design since pressure oscillations within the swirling flow itself help stabilize external
 oscillations
 - Don't worry if that doesn't make much sense!
- Better atomization of propellants in the cone sheets leads to smaller droplet sizes which also allows for better mixing
 - Also, the swirling gives the propellants radial, in addition to axial, momentum, meaning they have more time to mix when they
 enter the chamber

· Reduced worry of combustion instabilities


On the other hand, this design is not good for very viscous propellants because of the behavior of the swirlers, which reduces the atomization

Inner/External Mixing

A lot of design choices can be made that affect the overall behavior of this type of injector. One of the major choices is choosing whether to design for inner or external mixing.

External mixing is when the inner and outer cones are able to exit directly into the combustion chamber and mix that way.

Internal mixing is when the outlet for the inner swirler is recessed far back enough such that the inner cone collides with the wall of the outer swirler, pictured to the right.




This choice primarily affects the flow behavior (internal mixing can be more difficult to model), and the resultant angle, but there isn't very much research to back up giving a more specific description than this.

One final note: researching the coaxial swirl injector can be very difficult because a lot of the work on this type of injector was done by Soviet rocket engineers, and most of their records are no longer available or were simply never published. For this reason, you'll find conflicting information and many different names referring to the same thing (e.g. coax swirls are also known as bi-swirl coax, duplex, double simplexes, etc.). On the other hand, it has been used previously by NASA and notably by SpaceX's Raptor engine, so information might be found through their organizations.

Non-primary Injection

This is a very general class of injection that typically involves just designing holes or slots that serve a different purpose than the primary injector. Typically these are non-impinging holes implemented for cooling purposes within the chamber.

The most common of these is called **film cooling**. This is when some of the fuel or oxidizer is diverted from the main flow and injected almost parallel onto the walls of the combustion chamber. This forms a protective *film* of coolant along the chamber wall, which helps keep the chamber wall cool, as illustrated below.



Upstream of the Injector

What occurs upstream of the injector is very important to the design of the injector. Before the propellants enter the injector, several properties must be known in order to properly develop the geometry of the injector.

From the feed system, we must know the mass flow rate of both propellants, the total drop in pressure from their initial reservoir pressure, and the actual properties of either propellant (density, boiling point, etc.). It's useful to be very familiar with the actual behavior of the fluids, and knowing how, for example, the viscosity may play a role in the injection of the propellants can be critical.

Knowing the feed system inputs allows us to determine the desired aspects of the injector from the desired outputs of the entire engine – remember, think of the injector as the *interface* between the feed system and the rest of the engine.


Among the most important outputs of the system are the resulting mass flow rates, the pressure drop, and the vaporization length.

A good rule of thumb for initial injector design is that the drop in pressure across an orifice be **20%** of the chamber pressure (we discuss more on how to design for this later). This is also referred to as the **stiffness** of the injector. The relatively large difference in pressure forcefully pushes the propellants through the orifices with high velocity, which is vital to combustion stability. Without that high velocity out of the orifice, the propellants could be subject to flow dribble, where they tend to pool up at the orifice exit, causing poor mixing and hindering the flow into the chamber.

Pressure drop and flow rates also have some effect on combustion stability, but that's a very difficult topic that we won't cover very much here.

Manifold

The manifold is a space that properly reroutes the feed system propellant flow into the injector. It can also be thought of as an interface – this time between the feed system and the injector orifices. Below is a diagram of the Pyralis injector, with the fuel manifold in orange and the oxidizer manifold in green.



These spaces are specifically designed to evenly distribute the propellants across the face of the injector, allowing them to flow properly through the orifices. The manifold can also be vital for changing some aspects of the flow. For example, introducing a constriction in the manifold (called a *venturi*) is often used in pintle injectors to speed up the flow before it exits the orifices.

An important consideration for both manifold and injector design is whether to have the fuel or the oxidizer be the centermost propellant on the face of the injector. This decision has 2 consequences:

- 1. Any central propellant that does not directly impinge with the other propellant will go on to collide directly with the chamber wall.
 - a. Typically, the oxidizer is at a lower temperature than the fuel (most of the time, the oxidizer is cryogenic LOX). This allows us to use that unimpinged propellant as an *auxiliary coolant* for the chamber walls.
- 2. The outer propellant must be routed to the injector and comes in contact with more surface of the material used to make the injector.
 - a. If this outer propellant is LOX, we have to make sure that this material is **compatible with LOX**. Most materials are *not* compatible with LOX, which means it could cause problems like autoignition (very bad!!).
 - i. This is doubly so if the outer propellant is used for regenerative cooling because then it must flow through the entire length of the chamber, and so the entire chamber would have to be rated for LOX as well.

As such, we typically design manifolds as ox-centered, but this is not always the case.

Injector Geometry

Number of Elements/Orifices

The term *element* usually refers to the independent set of things that make up a unit of the injector, and varies from design to design. For example, in an impinging jet doublet, a pair of holes is an element, while in a coax swirl, the entire structure is an element.

You can have more than one element, and in some cases, like the impinging jet designs, you will have several of these. Deciding how many elements your injector will have is important because it directly affects the output of the injector (in terms of mass flow, propellant spread, etc.), but also can change other aspects of the geometry of each element.

The main consideration for each element is the size of its orifices. In general, the term *orifice* refers to a hole, but can also refer to a slot, annulus, or any general 'exit' for the propellant into the combustion chamber. Having more elements typically requires each element to have *smaller* orifices in order to supply the same mass flow, as you will see below.


Sizing

The sizing of orifices in an injector element typically comes from knowing the **desired mass flow rate** \dot{m} out of that orifice and the **desired pressure drop** ΔP across that orifice. Using the equation below, we can find A, the area needed for that orifice.

$$\dot{m} = C_d A \sqrt{2\rho \Delta P}$$

The two other variables, $\mathcal{C}d$ and ρ , are the coefficient of discharge and the density of the fluid going through the orifice, respectively.

The coefficient of discharge is a nondimensional number that tells us what fraction of mass flow going through an orifice actually 'gets through'. We can define it as the ratio of actual mass flow to theoretical mass flow out the end of an orifice, and so is between 0 and 1. We usually take an empirical estimate of this number based on the shape of the orifice (e.g. sharp corners experience more flow loss than round corners, so have a lower *Cd*, illustrated below).



This equation can also be used in reverse, taking a given area (or diameter of hole) and finding the resulting mass flow through that orifice. This can be very useful if there are hard-set manufacturing limits, and is also useful for designing non-primary injections.

In general, a **larger number of smaller holes** will result in more spread of your propellant and allow for better mixing and atomization throughout the combustion chamber.

Knowing this, you might wonder why we don't just use a very large number of very small holes to achieve the best performance. In fact, if all we cared about was engine performance, we would! The reason we don't is that we also have to *make* the engine ourselves, and choosing to design such precise and difficult-to-machine parts is incredibly tedious and, in some cases, impossible.

As such, <u>always be mindful of the actual manufacturing of the injector when sizing it</u>. Oftentimes, the part will be machined by hand, and you don't want to be the reason someone is stuck drilling 70 very precise 0.5 mm holes the night before their midterm (and you certainly don't want to be that person yourself!).

And another note, having a relatively large number of orifices can bring up even more concerns regarding combustion stability, due to more fine patterns causing more unstable energy/pressure fluctuations, but that's not a topic we'll delve into very deeply.

Angles


There are 2 important angles to keep track of in the design of the injector: the angle at which the propellant enters the combustion chamber, and the **resultant angle** of the fluids after impingement. Knowing the entry angle can typically get you a very good idea of the resultant angle

if you also know the momentums of the two streams.

Knowing the resultant angle is critical because you want the fluids to combust axially downwards, towards the nozzle exit, and not towards

$$\tan \beta = \frac{m_1 v_1 \sin \alpha_1 - m_2 v_2 \sin \alpha_2}{\dot{m}_1 v_1 \cos \alpha_1 + \dot{m}_2 v_2 \cos \alpha_2}$$

Where m is the mass flow rate, v is the velocity, the subscripts 1 and 2 refer to either propellant, and the angles are illustrated below.



In general, you want the resultant angle to be very close to zero (i.e. going straight down the chamber towards the nozzle exit). Note that we have to use my, the fluid's momentum per second (units Newtons) because the flow is a moving continuous mass.

Sometimes, though, this approximation does not match empirical data, like with pintle injectors (among other designs or variations). In these cases, there are often published empirical formulas that can be used to acquire a better approximation of the resultant angle.

Orifice Length

The actual length of the orifice, from entry to exit, is actually an important factor in determining the behavior of the fluid flow across the injector. What we want is an orifice long enough to avoid *flow separation*, a phenomenon we won't really discuss but just know that it can amplify *flow losses* – when the flow loses energy (and thus is slower, and can sometimes cause even more problems at the orifice exit or within the stream flow into the chamber). In addition, ensuring the orifice is an adequate size helps us also better avoid the problem of flow dribble that we mentioned earlier.


Most literature agrees that a good rule of thumb (at least for simple impinging jet orifices) is that the ratio of the orifice length to the orifice diameter (its L/d) should be at least 5. Having slightly less than this is sometimes ok, but it's best to aim for at least that, and not have an incredibly long orifice.

Summary

If you remember nothing from above, or just don't wanna read all that, at least remember these points!

- The injector is a part of the liquid rocket engine located between the feed system and the combustion chamber
- Its job is to inject the propellants (fuel/oxidizer) from the feed system into the combustion chamber in a way that
 - $\,^{\circ}\,$ Optimizes the flow/impingement \rightarrow optimizes combustion
 - Ensures combustion stability
 - o Makes sure the chamber walls don't melt

o Check out this video of a cold-flow test of a simple injector



- Mixing is the mixing of two different propellants into a local solution
 - The propellants need to be well-mixed in order to combust effectively
- Atomization is the breakup of a single propellant stream into individual droplets
 - Promotes vaporization, since it requires less energy to turn a single droplet into a vapor than an entire stream of fluid
 - This can be measured by a metric of 'average droplet size', and we want to minimize this, if possible
 - Very commonly used as a metric of 'average droplet size' is the Sauter mean diameter
- Vaporization is the conversion of liquid propellant into a vapor
 - o Most of the combustion in a liquid rocket engine occurs in the gas phase
 - It's critical that vaporization finishes before the propellants reach the end of the combustion chamber, and is measured using vaporization length
- The 3 common types of injectors we looked at were:
 - o Impinging jet: simply injects the propellants through angled orifices so they slam into each other really fast

Very simple to design, but combustion can be unstable

Like impinging (fuel on fuel, ox on ox) is good for atomization

Unlike impinging (fuel on ox) is good for mixing

Unlike doublets are used in our Helios engine!

Unlike Doublet

• Pintle: injects one propellant straight down the chamber, and the other radially

Relatively simple, better mixing

propellant loops back around in the chamber


Contributes to combustion stability, cooling, and heating
Used in our Romulus engine!

a) Axial flow

b) Radial flow

c) Combined flow engine!

• Coaxial swirl: swirls the two propellants in coaxial swirl chambers down towards the chamber, and injects the resulting cones of liquid film



- A good rule of thumb is to design the injector to have a pressure drop about equal to 20% of the chamber pressure
 - Using this formula

$$\dot{m} = C_d A \sqrt{2\rho \Delta P}$$

- Where Cd is the discharge coefficient, a nondimensional number that measures 'how much flow gets through an orifice' and can be estimated by the shape of the orifice
- In general, a larger number of smaller holes gives better mixing, atomization, and combustion efficiency
 - But we don't use this philosophy much because someone is gonna have to machine those tiny holes, and you'll wish it isn't you
 - There may also be worry of combustion instabilities as the number of orifices increases
- Knowing the entry angle of propellants into the chamber can give you a good estimate of the resultant angle after impingement
 - This is critical because we want the fluids going axially down the chamber towards the nozzle exit, not combusting onto the chamber walls
 - But some designs require more sophisticated empirical approximations
- The manifold is the space right before the orifices that makes sure the propellants are distributed evenly across the injector
 - o The shape and volume of the manifolds are designed for desirable flow behavior
 - Usually (but not always), we prefer to ox-center, meaning the (usually lower temperature) oxidizer is the central propellant so
 uncombusted oxidizer will land on the chamber wall and act as a coolant
- Rocket combustion always results in random chamber pressure fluctuations
 - · When these fluctuations get out of control, it's called combustion instability, and it's very very bad
 - The injector can be designed to help mitigate these instabilities

Return to Learning Curriculum

No labels