

- 1. A/C are forbidden to enter RWY by TWY B2.
- 2. All parking stands (except Nr. 215-216) can be used for engine idle test. Engine run-ups stand north of stand Nr.301 is available for ACFT type B747 and below. Stands Nr.301, Nr.302, Nr.303 shall not be used when engine run-ups stand is in use.
- 3.Stand Nr.223A: stand for Airbus A380.
- 4.Stand Nr.224: stand for aircraft cleaning.
- 5. **HS1 HS5** : Hot spot.
- TWR blind zone

All-day Construction

Post-flight Construction

Changes: Construction aera.