## A380航空器运行规则 Operational Rules for A380

- 1. A380无限制运行区运行规则
- 1.1 无限制运行区
- 1.1.1 跑道: 01/19跑道、36R/18L跑道;
- 1.1.2 滑行道: Y4(含)以东的所有滑行道;
- 1.1.3 停机位: 308、507-509、361、463、561;
- 1.2 A380在上述区域运行,按塔台管制员指令 滑行。
- 2. A380限制性运行区运行规则
- 2.1 限制性运行区
- 2.1.1 滑行道: EO-E8、AO、A1、G、H、Y1、Y2、 2.1.1 TWYs EO-E8, AO, A1, G, H, Y1, Y2, Y3(H以西)、G0-G7、H0-H2、H4-H7、 T1-T4(Y4以西)、T5-T6、J1-J2(T5以北)、 W2、W7、F2、F3、F4(Z3以东)、W3、 M4(Z3与F之间)、M7、Z3(M4与F2之间)、 F(W2与W7之间)、M5。
- 2.1.2 停机位: 212、221、701、702.
- 2.2 A380在上述区域运行时,除按塔台管制员 指令或引导车引领的路线滑行外,还应:
- 2.2.1 进港航空器,应在脱离跑道后将 外侧发动机(1号、4号)置于怠速状态;
- 2.2.2 出港航空器,应使外侧发动机(1号、4号) 置于怠速状态,直至进入跑道。
- 3. 除上述区域外,其他区域禁止A380飞机运行。

- 1. Rules for areas without operational limits:
- 1.1 Areas without operational limits:
- 1.1.1 RWY: 01/19, 18L/36R;
- 1.1.2 TWYs east of TWY Y4 (including).
- 1.1.3 Stands Nr. 308, 507-509, 361, 463, 561.
- 1.2 A380 operating within the above area, shall taxi following ATC instructions.
- 2. Rules for areas with operational limits:
- 2.1 Areas with operational limits:
- Y3(west of H), G0-G7, H0-H2, H4-H7, T1-T4(west of Y4), T5-T6, J1-J2(north of T5), W2, W7, F2, F3, F4(east of Z3), W3, M4(BTN Z3 & F), M7, Z3(BTN M4 & F2), F(BTN W2 & W7), M5.
- 2.1.2 Stands Nr. 212, 221, 701, 702.
- 2.2 When operating within the above area, A380 shall taxi following ATC instructions or follow-me vehicle, and shall obey the following:
- 2.2.1 Arrival aircraft shall keep the outboard engines(Nr.1 and Nr.4) in idle state after vacating RWY.
- 2.2.2 Departure aircraft, shall keep the outboard engines(Nr.1 and Nr.4) in idle state until entering RWY.
- 3. Areas not mentioned in item 1 and 2, A380 are strictly forbidden to operate within.

Changes: Operational limits areas.