
D-ATIS 128.6(DEP) 126.45(ARR) APP 124.85(127.7) AP01 119.7(127.7) AP02 119.25(127.7) AP03

ATC SURVEILLANCE MINIMUM 124.75(125.25)AP04 CHENGDU/Shuangliu 130.35(118.85) for RWY20L ZUUU CHENGDU/Shuangliu



雷达引导方法

20L/20R号跑道雷达引导方法

(1) MIKOS方向进港航空器:

雷达引导经MIKOS, OLSEP, ELBIB, TEGAR至AVBEL, 按管制员引导右转切入20L/20R号跑道盲降。

(2) FJC方向讲港航空器:

雷达引导经FJC, MUMIK, TEGAR至AVBEL, 按管制员引导右转切入20L/20R号跑道盲降。

(3) PANKO方向进港航空器:

雷达引导经PANKO飞向AVBEL,按管制员引导左转 建立20L/20R号跑道盲降。

(4) WFX方向进港航空器:

雷达引导经WFX, ATAPU至MADEM, 按管制员引导 左转切入20L/20R号跑道盲降。

无线电通信失效程序

参见中国AIP成都双流机场(ZUUU) AD2.22第5项。

Way of radar vectoring

Way of radar vectoring for RWY20L/20R

- (1) Arrival aircraft from MIKOS: Aircraft will be vectored to AVBEL via MIKOS, OLSEP, ELBIB and TEGAR, then turn RIGHT to establish RWY20L/20R ILS/DME approach by ATC instructions
- (2) Arrival aircraft from VOR 'FJC': Aircraft will be vectored to AVBEL via VOR 'FJC', MUMIK and TEGAR, then turn RIGHT to establish RWY20L/20R ILS/DME approach by ATC instructions.
- (3) Arrival aircraft from PANKO: Aircraft will be vectored to AVBEL via PANKO, then turn LEFT to establish RWY20L/20R ILS/DME approach by ATC instructions.
- (4) Arrival aircraft from VOR 'WFX': Aircraft will be vectored to MADEM via VOR 'WFX' and ATAPU, then turn LEFT to establish RWY20L/20R ILS/DME approach by ATC instructions.

Radio Communication failure procedures Refer to CHINA AIP ZUUU AD2.22 item 5.

Changes: New chart.

ZUUU AD2.24-6B EFF1405281600 2014-4-15 中国民用航空局CAAC