

Continuous-Time Linear Time-Invariant (LTI) System

沈威宇

October 4, 2026

Contents

1	Continuous-Time Linear Time-Invariant (LTI) System	1
I	Definition	1
	i Causal continuous-time linear time-invariant (LTI) system	1
	ii Non-causal continuous-time linear time-invariant (LTI) system.	1
	iii Gain	1
	iv Order	1
II	Response	2
	i Poles and zeros	2
	ii Transient response.	2
	iii Time constant.	2
	iv Natural frequency	2
	v Resonance	2
III	Stability	3
	i Asymptotically stable or bounded-input bounded-output (BIBO) stable	3
	ii (Lyapunov) stable	3
	iii Marginally stable	3
	iv Unstable	3
IV	Frequency response	3
	i Frequency response	3
	ii Steady-state sinusoidal response	3
	iii Logarithmic scale, decibel (dB), and Bode plot (波德圖)	5
	iv Cutoff (截止), break, or corner (angular) frequency	6
	v Normalizing	6
	vi Bode plot.	6

V	Filters	6
i	Low-pass or lowpass (低通) (LP), high-cut, or bass-cut filter (LPF)	6
ii	High-pass or highpass (高通) (HP), low-cut, or treble-cut filter (HPF)	7
iii	Band-pass or bandpass (BP) filter (BPF)	7
iv	Band-stop or bandstop (BS), band-reject, or notch filter (BSF)	7
v	Bandwidth	8
vi	Normalized low-pass prototype filter	8
vii	Butterworth filter or maximally flat magnitude filter	8
viii	single-time-constant (STC) filters.	9
VI	Transfer function factors	9
i	Reciprocal factor	10
ii	Ramp factor	10
iii	Low-pass factor	11
iv	High-pass factor	11
v	Quadratic low-pass factor	12
vi	Band-pass factor	14
vii	Band-stop factor	15

1 Continuous-Time Linear Time-Invariant (LTI) System

I Definition

i Causal continuous-time linear time-invariant (LTI) system

A causal continuous-time linear time-invariant (LTI) system of a variable $t \in \mathbb{R}$ is a system that accept an input (distribution) (often called function) $x(t)$ and produces a response (distribution) (often called function) $y(t)$ that is the solution of a linear autonomous ODE whose forcing term is $x(t)$, called governing equation, given initial condition $y(0) = 0$. It can be completely characterized by a distribution called impulse response (function) $h(t)$, which is the output when the input is the Dirac delta function $\delta(t)$ and is such that $h(t) = 0$ for all $t < 0$, that

$$y(t) = (x * h)(t) := \int_0^t x(\tau)h(t - \tau) d\tau.$$

Applying unilateral Laplace transform

$$Y(s) = X(s) \cdot H(s),$$

where $H(s)$ is a rational function called transfer function (轉移函數). Unless otherwise specified, we will discuss casual continuous-time linear time-invariant (LTI) system below.

ii Non-causal continuous-time linear time-invariant (LTI) system

A non-causal continuous-time linear time-invariant (LTI) system of a variable $t \in \mathbb{R}$ is a system that accept an input (distribution) (often called function) $x(t)$ and produces a response (distribution) (often called function) $y(t)$ that is the solution of a linear autonomous ODE whose forcing term is $x(t)$, called governing equation. It can be completely characterized by a distribution called impulse response (function) $h(t)$, which is the output when the input is the Dirac delta function $\delta(t)$, that

$$y(t) = (x * h)(t) := \int_{-\infty}^{\infty} x(\tau)h(t - \tau) d\tau.$$

Applying bilateral Laplace transform

$$Y(s) = X(s) \cdot H(s),$$

where $H(s)$ is a rational function called transfer function.

iii Gain

$|H(s)|$ is called gain (增益), or attenuation (衰減量) if < 1 .

iv Order

The number of poles of $H(s)$ is called the order of the system.

II Response

i Poles and zeros

Since $H(s)$ is rational, a complex conjugate of a pole is a pole of same order, and a complex conjugate of a zero is a zero of same order.

A pole-zero plot or pole-zero constellation is a graphical representation showing poles and zeros of a transfer function in the complex plane.

ii Transient response

A response component that converges to an equilibrium as t gets large. Such converged state is called steady state or transient state.

iii Time constant

For a response in the form

$$y(t) = A + \sum_{j=1}^n B_j e^{-\frac{t}{\tau_j}}$$

with $A \in \mathbb{R}$, $B_j \neq 0$, and $\tau_j > 0$.

Each τ_j is called a time constant, and the system is called a n -time-constant system, e.g., single-time-constant (STC), two-time-constant (TTC).

For each term

$$y_j(t) = B_j e^{-\frac{t}{\tau_j}}$$

if $B_j > 0$, we typically call that

- $y_j(t)$ decays to 0 about $5\tau_j$.
- The falling time or pulse decay time is defined as the time $y_j(t)$ changes from $0.9B_j$ to $0.1B_j$, which is $\ln 9\tau_j \approx 2.2\tau$.

if $B_j < 0$, we typically call that

- $y_j(t)$ grows to B_j about $5\tau_j$.
- The rising time or pulse grow time is defined as the time $y_j(t)$ changes from $0.1B_j$ to $0.9B_j$, which is $\ln 9\tau_j \approx 2.2\tau$.

iv Natural frequency

For a pair of conjugate poles $\pm i\omega$ of $H(s)$, ω is called a natural frequency of the system.

v Resonance

Resonance occurs when the input and transfer function have common poles on the imaginary axis. Such natural frequency is called resonant/resonance frequency.

III Stability

i Asymptotically stable or bounded-input bounded-output (BIBO) stable

A LTI system is called asymptotically stable or bounded-input bounded-output stable iff bounded input implies bounded response, iff all poles of it are on the left half-plane iff $h(t)$ is absolutely integrable.

ii (Lyapunov) stable

A LTI system is called (Lyapunov) stable iff there is no pole of it on the right half-plane and no multiple pole of it on the imaginary axis iff $h(t)$ is bounded.

iii Marginally stable

A LTI system is called marginally stable iff it is stable but not asymptotically stable.

iv Unstable

A LTI system is called unstable iff it is not stable.

IV Frequency response

i Frequency response

- $H(i\omega)$ is called frequency response,
- $a(\omega) := |H(i\omega)|$ is called magnitude/amplitude response/ratio or gain,
- $\theta(\omega) := \arg(H(i\omega))$ (also denoted as $\varphi(\omega)$) is called phase (angle) response/shift.

ω is called angular frequency and $f := \frac{\omega}{2\pi}$ is called non-angular frequency. Both can be called frequency and can be differentiated with symbol, and angular frequency is used below.

ii Steady-state sinusoidal response

Assume the system is stable with m LHP poles $a_1, \dots, a_n$ and n pure imaginary poles $b_1, \dots, b_n$ and that $H(s) = O(1)$. When the input is $x(t) = e^{i\omega t}$, $X(s) = \frac{1}{s - i\omega}$, the response is

$$Y(s) = \frac{H(s)}{s - i\omega}.$$

$$y(t) = \frac{1}{2\pi i} \lim_{T \rightarrow \infty} \int_{\gamma - iT}^{\gamma + iT} Y(s) e^{st} ds, \quad \gamma > 0.$$

Close the contour from $\gamma - iT$ to $\gamma + iT$ with a semicircular contour C_T

$$C_T = \{\gamma + iT e^{i\theta} : \theta \in [0, \pi]\}$$

to form a closed contour Γ_T .

$$\begin{aligned} \left| \int_{C_T} Y(s) e^{st} ds \right| &= \left| \int_{C_T} Y(s) e^{(\gamma - T \sin \theta)t} e^{i \Im(s)t} ds \right| \\ &= \int_0^\pi \left| Y(\gamma + iT e^{i\theta}) e^{(\gamma - T \sin \theta)t} (-T e^{i\theta}) \right| d\theta \\ &\leq T e^{\gamma t} \int_0^\pi |Y(\gamma + iT e^{i\theta})| e^{-T \sin \theta t} d\theta \end{aligned}$$

$$Y(s) = O\left(\frac{1}{s}\right)$$

Suppose for some $M > 0$, for all sufficiently large $|s|$,

$$|Y(s)| \leq \frac{M}{|s|}$$

For all sufficiently large T ,

$$\begin{aligned} |\gamma + iT e^{i\theta}| &\geq T - \gamma \\ |Y(\gamma + iT e^{i\theta})| &\leq \frac{M}{T - \gamma} = O\left(\frac{1}{T}\right) \\ T e^{\gamma t} \int_0^\pi |Y(\gamma + iT e^{i\theta})| e^{-T \sin \theta t} d\theta &= O\left(\int_0^\pi e^{-T \sin \theta t} d\theta\right) \\ \int_0^\pi e^{-T \sin \theta t} d\theta &= 2 \int_0^{\frac{\pi}{2}} e^{-T \sin \theta t} d\theta \\ \sin \theta &\geq \frac{2\theta}{\pi} \\ e^{-T \sin \theta t} &\leq e^{-\frac{2T\theta t}{\pi}} \\ 2 \int_0^{\frac{\pi}{2}} e^{-T \sin \theta t} d\theta &\leq 2 \int_0^{\frac{\pi}{2}} e^{-\frac{2T\theta t}{\pi}} d\theta \\ &= 2 \frac{\pi}{2Tt} \left\{ e^{-\frac{2T\theta t}{\pi}} \right\} \Big|_0^{\frac{\pi}{2}} \\ &= \frac{\pi}{Tt} (1 - e^{-Tt}) \\ &\leq \frac{\pi}{Tt} \end{aligned}$$

$$\begin{aligned} 2 \int_0^{\frac{\pi}{2}} e^{-T \sin \theta t} d\theta &= O\left(\frac{1}{T}\right) \\ T e^{\gamma t} \int_0^\pi |Y(\gamma + iT e^{i\theta})| e^{-T \sin \theta t} d\theta &= O\left(\frac{1}{T}\right) \end{aligned}$$

Thus,

$$\begin{aligned} \lim_{T \rightarrow \infty} \int_{C_T} Y(s) e^{st} ds &= 0 \\ y(t) &= \frac{1}{2\pi i} \lim_{T \rightarrow \infty} \int_{\Gamma} Y(s) e^{st} ds \end{aligned}$$

Since $H(s)$ is meromorphic, by residue theorem,

$$y(t) = \text{Res}(Y(s) e^{st}, i\omega) + \sum_{k=1}^m \text{Res}(Y(s) e^{st}, a_k) + \sum_{k=1}^n \text{Res}(Y(s) e^{st}, b_k)$$

Use Laurent series:

$$\text{Res}(Y(s)e^{st}, z) = \lim_{s \rightarrow z} (s - z)Y(s)e^{st} = e^{zt} \lim_{s \rightarrow z} (s - z)Y(s)$$

$\sum_{k=1}^m \text{Res}(Y(s)e^{st}, a_k)$ is transient response.

- If $n = 0$, the system is asymptotically stable, and

$$\text{Res}(Y(s)e^{st}, i\omega) = H(i\omega)e^{i\omega t}$$

is steady-state sinusoidal response with amplitude $a(\omega)$.

- If $n > 0$, the system is marginally stable, and:
 - If $i\omega$ is not a pole,

$$\text{Res}(Y(s)e^{st}, i\omega) + \sum_{k=1}^n \text{Res}(Y(s)e^{st}, b_k) = H(i\omega)e^{i\omega t} + \sum_{k=1}^n e^{b_k t} \lim_{s \rightarrow b_k} (s - b_k)Y(s)$$

is steady-state sinusoidal response and the second term is not transient.

- If $i\omega$ is a pole, it is resonant response that grows to infinity over time.

iii Logarithmic scale, decibel (dB), and Bode plot (波德圖)

Frequency response are often expressed in logarithmic scale:

- Magnitude response, input, and output can be expressed in decibel (dB) as $g(\omega) := C \log_{10}|H(i\omega)|$, $C \log_{10}|x|$, and $C \log_{10}|y|$ with some constant C . $C = 20$ is used here.
- Changing by 2 times is called an octave or oct, and changing by 10 times is called a decade or dec. $k \text{ dec}^{-1}$ equals to $\log_{10}(2) \text{ oct}^{-1}$. The most common used is 20 dB/dec equals to $20 \log_{10}(2) \approx 6 \text{ dB/oct}$.

We can factor $H(s)$ into

$$H(s) = G \prod_{k=1}^m H_k(s)$$

then

$$a(\omega) = |G| \prod_{k=1}^m |H_k(i\omega)|$$

$$g(\omega) = 20 \log_{10} |G| + 20 \sum_{k=1}^m \log_{10} |H_k(i\omega)|$$

$$\theta(\omega) = \arg(G) + \sum_{k=1}^m \arg(H_k(i\omega))$$

iv Cutoff (截止), break, or corner (angular) frequency

For a transfer function, cutoff frequency ω_c is a frequency such that

$$|H(i\omega_c)| = \frac{\max_{\omega} a(\omega)}{\sqrt{2}}.$$

$20 \log_{10}\left(\frac{1}{\sqrt{2}}\right) = -10 \log_{10}(2) \approx -3$, thus this frequency is also denoted $\omega_{-3\text{dB}}$ or $\omega_{3\text{dB}}$.

v Normalizing

For a transfer function $H(s)$ such that

$$\max_{\omega} a(\omega) = K \in \mathbb{R}_{>0},$$

normalizing means dividing $H(s)$ by K . The following filter definitions are normalized. Non-normalized definition is defined as any filter whose normalized form complies with the definition.

vi Bode plot

- Bode magnitude plot or dB gain curve: Magnitude response plotted with frequency (or frequency divided by cutoff or some other important frequency) in logarithmic scale as horizontal axis and magnitude response (or, normalized magnitude response, that is, divided by maximum gain, where the Bode magnitude plot is called normalized) in dB as vertical axis.
- Bode phase plot or phase curve: Phase response plotted with frequency (or frequency divided by cutoff or some other important frequency) in logarithmic scale as horizontal axis and phase response as vertical axis.
- Asymptotic Bode plot: The asymptotes of Bode plots for low and high frequency is often interested.

V Filters

i Low-pass or lowpass (低通) (LP), high-cut, or bass-cut filter (LPF)

A continuous-time linear time-invariant system is a normalized low-pass filter iff $H(i\omega)$ as a function of a real variable ω is such that

$$\lim_{\omega \rightarrow 0} a(\omega) = 1$$

$$\lim_{\omega \rightarrow \infty} a(\omega) = 0$$

K is called low-pass gain.

Ideal normalized low-pass filter is

$$H(i\omega) = \begin{cases} 1, & \omega < \omega_0 \\ 0, & \omega > \omega_0 \end{cases}$$

ii High-pass or highpass (高通) (HP), low-cut, or treble-cut filter (HPF)

A continuous-time linear time-invariant system is a normalized high-pass filter iff $H(i\omega)$ as a function of a real variable ω is such that

$$\lim_{\omega \rightarrow 0} a(\omega) = 0$$

$$\lim_{\omega \rightarrow \infty} a(\omega) = 1$$

K is called high-pass gain.

Ideal normalized high-pass filter is

$$H(i\omega) = \begin{cases} 1, & \omega > \omega_0 \\ 0, & \omega < \omega_0 \end{cases}$$

iii Band-pass or bandpass (BP) filter (BPF)

A continuous-time linear time-invariant system is a standard normalized band-pass filter iff $H(i\omega)$ as a function of a real variable ω is such that

$$\lim_{\omega \rightarrow 0} a(\omega) = 0$$

$$\lim_{\omega \rightarrow \infty} a(\omega) = 0$$

$$\arg_{\omega} \left\{ a(\omega) = \frac{1}{\sqrt{2}} \right\} = \omega_L, \omega_H$$
$$|H(\sqrt{\omega_L \omega_H})| = 1$$

where $\omega_L < \omega_H$ are called band edge, $\omega_H - \omega_L$ is called bandwidth, and $\omega_0 = \sqrt{\omega_L \omega_H}$ is called central passed frequency or center frequency. $\omega_0 \gg B$ is called narrow band-pass filter.

K is called band-pass or midband gain.

Ideal normalized band-pass filter is

$$H(i\omega) = \begin{cases} 1, & \omega_H > \omega > \omega_L \\ 0, & \omega < \omega_L \vee \omega > \omega_H \end{cases}$$

iv Band-stop or bandstop (BS), band-reject, or notch filter (BSF)

A continuous-time linear time-invariant system is a standard normalized band-stop filter iff $H(i\omega)$ as a function of a real variable ω is such that

$$\arg_{\omega} \left\{ a(\omega) = \frac{1}{\sqrt{2}} \right\} = \omega_L, \omega_H$$
$$|H(\sqrt{\omega_L \omega_H})| = 0$$

where $\omega_L < \omega_H$ are called band edge, $\omega_H - \omega_L$ is called bandwidth, and $\omega_0 = \sqrt{\omega_L \omega_H}$ is called central rejected frequency or center frequency. $\omega_0 \gg B$ is called narrow band-stop filter.

K is called notch gain.

Ideal normalized band-stop filter is

$$H(i\omega) = \begin{cases} 0, & \omega_H > \omega > \omega_L \\ 1, & \omega < \omega_L \vee \omega > \omega_H \end{cases}$$

v Bandwidth

The band of frequencies over which the gain is no less than 3 dB (or other value if specified, such as 0 dB for unity gain bandwidth), or the length of it if it is connected.

vi Normalized low-pass prototype filter

A normalized low-pass prototype filter is a low-pass filter with cutoff frequency $\omega_c = 1$. Suppose the transfer function of it is $H_P(s)$. A normalized low-pass prototype filter is usually defined with $(a(\omega))^2 = H(i\omega)H(-i\omega)$ or $H(s)$.

To transform an n th-order normalized low-pass prototype filter to an n th-order low-pass filter with cutoff frequency ω_c , use the transfer function

$$H_{LP}(s) = H_P\left(\frac{s}{\omega_c}\right).$$

To transform an n th-order normalized low-pass prototype filter to an n th-order high-pass filter with cutoff frequency ω_c , use the transfer function

$$H_{HP}(s) = H_P\left(\frac{\omega_c}{s}\right).$$

To transform an n th-order normalized low-pass prototype filter to a $2n$ th-order standard band-pass filter with cutoff frequency ω_c , use the transfer function

$$H_{BP}(s) = H_P\left(\frac{s^2 + \omega_0^2}{Bs}\right).$$

To transform an n th-order normalized low-pass prototype filter to a $2n$ th-order standard band-stop filter with cutoff frequency ω_c , use the transfer function

$$H_{BS}(s) = H_P\left(\frac{Bs}{s^2 + \omega_0^2}\right).$$

vii Butterworth filter or maximally flat magnitude filter

n th-order Butterworth low-pass prototype filter is

$$(a(\omega))^2 = \frac{1}{1 + \omega^{2n}}$$

$$H(s) = \prod_{k=1}^n \frac{1}{s - e^{\frac{j(2k+n-1)\pi}{2n}}}$$

For first-order,

$$(a(\omega))^2 = \frac{1}{1 + \omega^2}$$
$$H(s) = \frac{1}{s + 1}$$

When not specified, a filter of a type usually refers to the lowest-order Butterworth filter of the type.

viii single-time-constant (STC) filters

ω_c is cutoff frequency, τ is time constant, $|K|$ is gain at $\omega = 0$, and the following form is called standard form.

Low-pass:

$$H(s) = \frac{K}{1 + \frac{s}{\omega_c}}$$
$$H(i\omega) = \frac{K}{1 + i\frac{\omega}{\omega_c}}$$
$$a(\omega) = \frac{|K|}{\sqrt{1 + \left(\frac{\omega}{\omega_c}\right)^2}}$$
$$\theta(\omega) = -\arg\left(\frac{\omega}{\omega_c}\right)$$
$$H(i0) = K$$
$$H(i\infty) = 0$$
$$\tau = \frac{1}{\omega_c}$$

High-pass:

$$H(s) = \frac{K}{1 - \frac{s}{\omega_c}}$$
$$H(i\omega) = \frac{K}{1 - i\frac{\omega}{\omega_c}}$$
$$a(\omega) = \frac{|K|}{\sqrt{1 - \left(\frac{\omega}{\omega_c}\right)^2}}$$
$$\theta(\omega) = \arg\left(\frac{\omega}{\omega_c}\right)$$
$$H(i0) = 0$$
$$H(i\infty) = K$$
$$\tau = \frac{1}{\omega_c}$$

VI Transfer function factors

Variables after ; are parameters, which are positive real numbers unless otherwise specified. Only positive ω are considered.

i Reciprocal factor

This factor is not asymptotically stable but marginally stable.

$$\begin{aligned}H_c(s; W) &:= \frac{W}{s} \\H_c(i\omega; W) &= \frac{W}{i\omega} \\a_c(\omega; W) &= \frac{W}{\omega} \\g_c(\omega; W) &= -20 \log_{10}(\omega) + 20 \log_{10}(W) \\\theta_c(\omega; W) &= -\frac{\pi}{2}\end{aligned}$$

Bode magnitude plot has slope -20 dB/dec, y intercept $20 \log_{10}(W)$, and x intercept $-\log_{10}(W)$.

Limit:

- For $\omega \gg W$:

$$\begin{aligned}a_c(\omega) &\approx 0 \\g_c(\omega) &\approx -\infty\end{aligned}$$

- For $\omega \ll W$:

$$\begin{aligned}a_c(\omega) &\approx \infty \\g_c(\omega) &\approx \infty\end{aligned}$$

ii Ramp factor

$$\begin{aligned}H_r(s; W) &:= \frac{s}{W} \\H_r(i\omega; W) &= \frac{i\omega}{W} \\a_r(\omega; W) &= \frac{\omega}{W} \\g_r(\omega; W) &= 20 \log_{10}(\omega) - 20 \log_{10}(W) \\\theta_r(\omega; W) &= \frac{\pi}{2}\end{aligned}$$

Bode magnitude plot has slope 20 dB/dec, y intercept $-20 \log_{10}(W)$, and x intercept $\log_{10}(W)$.

Limit and cutoff frequency:

- For $\omega \gg W$:

$$\begin{aligned}a_r(\omega; W) &\approx \infty \\g_r(\omega; W) &\approx \infty\end{aligned}$$

- For cutoff frequency $\omega = \omega_c = \frac{W}{\sqrt{2}}$:

$$\begin{aligned}a_r(\omega; W) &= \frac{1}{\sqrt{2}} \\g_r(\omega; W) &= -10 \log_{10}(2)\end{aligned}$$

- For $\omega \ll W$:

$$\begin{aligned}a_r(\omega; W) &\approx 0 \\g_r(\omega; W) &\approx -\infty\end{aligned}$$

iii Low-pass factor

$$H_{LP}(s; \omega_c) := \frac{\omega_c}{s + \omega_c}$$

$$H_{LP}(i\omega; \omega_c) = \frac{\omega_c}{i\omega + \omega_c}$$

$$a_{LP}(\omega; \omega_c) = \frac{\omega_c}{\sqrt{\omega^2 + \omega_c^2}}$$

$$g_{LP}(\omega; \omega_c) = 20 \log_{10}(\omega_c) - 10 \log_{10}(\omega^2 + \omega_c^2)$$

$$\theta_{LP}(\omega; \omega_c) = -\arg(i\omega + \omega_c)$$

Asymptotic Bode plot and cutoff frequency:

- For $\omega \gg \omega_c$:

$$a_{LP}(\omega; \omega_c) \approx \frac{\omega_c}{\omega}$$

$$g_{LP}(\omega; \omega_c) \approx 20 \log_{10}(\omega_c) - 20 \log_{10}(\omega),$$

which is slant asymptote with slope -20 dB/dec, y intercept $20 \log_{10}(\omega_c)$, and x intercept $\log_{10}(\omega_c)$.

$$\theta_{LP}(\omega; \omega_c) \approx 0$$

- For cutoff frequency $\omega = \omega_c$:

$$a_{LP}(\omega; \omega_c) = \frac{1}{\sqrt{2}}$$

$$g_{LP}(\omega; \omega_c) = -10 \log_{10}(2)$$

$$\theta_{LP}(\omega; \omega_c) = -\frac{\pi}{4}$$

- For $\omega \ll \omega_c$:

$$a_{LP}(\omega; \omega_c) \approx 1$$

$$g_{LP}(\omega; \omega_c) \approx 0,$$

which is horizontal asymptote $g_{LP} = 0$.

$$\theta_{LP}(\omega; \omega_c) \approx -\frac{\pi}{2}$$

iv High-pass factor

$$H_{HP}(s; \omega_c) := \frac{s}{s + \omega_c}$$

$$H_{HP}(i\omega; \omega_c) = \frac{i\omega}{i\omega + \omega_c}$$

$$a_{HP}(\omega; \omega_c) = \frac{\omega}{\sqrt{\omega^2 + \omega_c^2}}$$

$$g_{HP}(\omega; \omega_c) = 20 \log_{10}(\omega) - 10 \log_{10}(\omega^2 + \omega_c^2)$$

$$\theta_{HP}(\omega; \omega_c) = \frac{\pi}{2} - \arg(i\omega + \omega_c)$$

Asymptotic Bode plot and cutoff frequency:

- For $\omega \gg \omega_c$:

$$a_{LP}(\omega; \omega_c) \approx 1$$

$$g_{HP}(\omega; \omega_c) \approx 0,$$

which is horizontal asymptote $g_{HP} = 0$.

$$\theta_{HP}(\omega; \omega_c) \approx \frac{\pi}{2} - \frac{\pi}{2} = 0$$

- For cutoff frequency $\omega = \omega_c$:

$$a_{HP}(\omega; \omega_c) = \frac{1}{\sqrt{2}}$$

$$g_{HP}(\omega; \omega_c) = -10 \log_{10}(2)$$

$$\theta_{HP}(\omega; \omega_c) = \frac{\pi}{4}$$

- For $\omega \ll \omega_c$:

$$a_{HP}(\omega; \omega_c) \approx \frac{\omega}{\omega_c}$$

$$g_{HP}(\omega; \omega_c) \approx 20 \log_{10}(\omega) - 20 \log_{10}(\omega_c),$$

which is slant asymptote with slope 20 dB/dec, y intercept $-20 \log_{10}(\omega_c)$, and x intercept $\log_{10}(\omega_c)$.

$$\theta_{HP}(\omega; \omega_c) \approx \frac{\pi}{2}$$

v Quadratic low-pass factor

$$H_{QD}(s; \omega_0, Q) := \frac{\omega_0^2}{s^2 + \frac{\omega_0}{Q}s + \omega_0^2}, \quad Q \geq \frac{1}{2}$$

$$H_{QD}(i\omega; \omega_0, Q) = \frac{\omega_0^2}{-\omega^2 + i\frac{\omega_0}{Q}\omega + \omega_0^2}$$

$$a_{QD}(\omega; \omega_0, Q) = \frac{\omega_0^2}{\sqrt{\frac{\omega_0^2}{Q^2}\omega^2 + \omega^4 + \omega_0^4 - 2\omega^2\omega_0^2}}$$

$$\frac{d}{d\omega} (a_{QD}(\omega; \omega_0, Q)) = \frac{-\frac{\omega_0^4}{Q^2}\omega - 2\omega^3\omega_0^2 + 2\omega\omega_0^4}{\left(\frac{\omega_0^2}{Q^2}\omega^2 + \omega^4 + \omega_0^4 - 2\omega^2\omega_0^2\right)^{\frac{3}{2}}}$$

$$\left. \frac{d}{d\omega} (a_{QD}(\omega; \omega_0, Q)) \right|_{\omega=\omega_p} = 0$$

$$\omega_p = \omega_0 \sqrt{1 - \frac{1}{2Q^2}}, \quad Q > \frac{1}{\sqrt{2}}$$

$$\theta_{QD}(\omega; \omega_0, Q) = -\arg\left(-\omega^2 + i\frac{\omega_0}{Q}\omega + \omega_0^2\right)$$

- If $Q \geq \frac{1}{2}$, it is a low-pass filter.

- If $Q > \frac{1}{2}$, the maximum of g_{QD} occurs at peak frequency $\omega = \omega_p = \omega_0 \sqrt{1 - \frac{1}{2Q^2}}$.
- If $Q = \frac{1}{2}$, at $\omega = \omega_0 \sqrt{1 - \frac{1}{2Q^2}} = 0$,

$$a_{QD}(\omega; \omega_0, Q) = \infty$$

$$g_{QD}(\omega; \omega_0, Q) = \infty$$

- If $Q < \frac{1}{2}$, it is unstable.

Asymptotic Bode plot and center and peak frequencies:

- For $\omega \ll \omega_0, \frac{\omega_0}{Q}$:

$$a_{QD}(\omega; \omega_0, Q) \approx 1$$

$$g_{QD}(\omega; \omega_0, Q) \approx 0,$$

which is horizontal asymptote $g_{QD} = 0$.

$$\theta_{QD}(\omega; \omega_0, Q) \approx 0$$

- For center frequency $\omega = \omega_0$:

$$|H_{QD}(i\omega; \omega_0, Q)| = Q$$

$$g_{QD}(\omega; \omega_0, Q) = 20 \log_{10}(Q)$$

$$\theta_{QD}(\omega; \omega_0, Q) = -\frac{\pi}{2}$$

- If $Q > \frac{1}{2}$, for peak frequency $\omega = \omega_p = \omega_0 \sqrt{1 - \frac{1}{2Q^2}}$:

$$a_{QD}(\omega; \omega_0, Q) = \frac{\omega_0^2}{\sqrt{\frac{\omega_0^4}{Q^2} - \frac{\omega_0^4}{2Q^4} + \omega_0^4 - \frac{\omega_0^4}{Q^2} + \frac{\omega_0^4}{4Q^4} + \omega_0^4 - 2\omega_0^4 + \frac{\omega_0^4}{Q^2}}} = \frac{Q}{\sqrt{1 - \frac{1}{4Q^2}}}$$

$$g_{QD}(\omega; \omega_0, Q) = 20 \log_{10}(Q) - 10 \log_{10}\left(1 - \frac{1}{4Q^2}\right),$$

which are maxima $a_{QD} = \frac{Q}{\sqrt{1 - \frac{1}{4Q^2}}}$ and $g_{QD} = 20 \log_{10}(Q) - 10 \log_{10}\left(1 - \frac{1}{4Q^2}\right)$.

- For $\omega \gg \omega_0, \frac{\omega_0}{Q}$:

$$a_{QD}(\omega; \omega_0, Q) \approx \frac{\omega_0^2}{\omega^2}$$

$$g_{QD}(\omega; \omega_0, Q) \approx 40 \log_{10}(\omega_0) - 40 \log_{10}(\omega)$$

which is slant asymptote with slope -40 dB/dec, y intercept $40 \log_{10}(\omega_0)$, and x intercept $\log_{10}(\omega_0)$.

$$\theta_{QD}(\omega; \omega_0, Q) \approx -\pi$$

vi Band-pass factor

$$H_{BP}(s; B, \omega_0) := \frac{Bs}{s^2 + Bs + \omega_0^2}$$

$$H_{BP}(i\omega; B, \omega_0) = \frac{iB\omega}{-\omega^2 + iB\omega + \omega_0^2}$$

$$a_{BP}(\omega; B, \omega_0) = \frac{B\omega}{\sqrt{B^2\omega^2 + \omega^4 + \omega_0^4 - 2\omega^2\omega_0^2}}$$

$$\frac{d}{d\omega} (a_{BP}(\omega; B, \omega_0)) = \frac{B(\omega^4 + \omega_0^4 - 2\omega^2\omega_0^2 + 2\omega^3 - 2\omega\omega_0^2)}{(B^2\omega^2 + \omega^4 + \omega_0^4 - 2\omega^2\omega_0^2)^{\frac{3}{2}}}$$

$$\left. \frac{d}{d\omega} (a_{BP}(\omega; B, \omega_0)) \right|_{\omega=\omega_0} = 0$$

$$\theta_{BP}(\omega; B, \omega_0) = \frac{\pi}{2} - \arg(-\omega^2 + iB\omega + \omega_0^2)$$

Asymptotic Bode plot and center and peak frequency:

- For $\omega \gg \omega_0, B$:

$$a_{BP}(\omega; B, \omega_0) \approx \frac{B}{\omega}$$

$$g_{BP}(\omega; B, \omega_0) \approx -20 \log_{10}(\omega) + 20 \log_{10}(B)$$

which is slant asymptote with slope -20 dB/dec, y intercept $20 \log_{10}(B)$, and x intercept $\log_{10}(B)$.

$$\theta_{BP}(\omega; B, \omega_0) \approx -\frac{\pi}{2}$$

- For center and peak frequency $\omega = \omega_0$:

$$a_{BP}(\omega; B, \omega_0) = 1$$

$$g_{BP}(\omega; B, \omega_0) = 0$$

which are maxima $a_{BP} = 1$ and $g_{BP} = 0$.

$$\theta_{BP}(\omega; B, \omega_0) = 0$$

- For $\omega \ll \omega_0, B$:

$$a_{BP}(\omega; B, \omega_0) \approx \frac{B\omega}{\omega_0^2}$$

$$g_{BP}(\omega; B, \omega_0) \approx 20 \log_{10}(\omega) + 20 \log_{10}(B) - 40 \log_{10}(\omega_0),$$

which is slant asymptote with slope 20 dB/dec, y intercept $20 \log_{10}(B) - 40 \log_{10}(\omega_0)$, and x intercept $2 \log_{10}(\omega_0) - \log_{10}(B)$.

$$\theta_{BP}(\omega; B, \omega_0) \approx \frac{\pi}{2}$$

vii Band-stop factor

$$H_{BS}(s; B, \omega_0) := \frac{s^2 + \omega_0^2}{s^2 + Bs + \omega_0^2}$$

$$H_{BS}(i\omega; B, \omega_0) = \frac{-\omega^2 + \omega_0^2}{-\omega^2 + iB\omega + \omega_0^2}$$

$$a_{BS}(\omega; B, \omega_0) = \frac{-\omega^2 + \omega_0^2}{\sqrt{B^2\omega^2 + \omega^4 + \omega_0^4 - 2\omega^2\omega_0^2}}$$

$$\theta_{BS}(\omega; B, \omega_0) = \arg\left(\frac{-\omega^2 + \omega_0^2}{-\omega^2 + iB\omega + \omega_0^2}\right)$$

Asymptotic Bode plot and center frequency:

- For $\omega \gg \omega_0, B$:

$$a_{BS}(\omega; B, \omega_0) \approx 1$$

$$g_{BS}(\omega; B, \omega_0) \approx 0,$$

which is horizontal asymptote $g_{BS} = 0$.

$$\theta_{BS}(\omega; B, \omega_0) \approx 0$$

- For center frequency $\omega = \omega_0$:

$$a_{BS}(\omega; B, \omega_0) = 0$$

$$g_{BS}(\omega; B, \omega_0) = -\infty$$

$$\theta_{BS}(\omega; B, \omega_0) = \arg(0) = \text{undefined}$$

- For $\omega \ll \omega_0, B$:

$$a_{BS}(\omega; B, \omega_0) \approx 1$$

$$g_{BS}(\omega; B, \omega_0) \approx 0$$

which is horizontal asymptote $g_{BS} = 0$.

$$\theta_{BS}(\omega; B, \omega_0) \approx 0$$