

Sym.: Base: Mods: FRow: Sym.2: Sett.: ARTSEY: ARTSEY num: ARTSEY sym: ARTSEY paren:...

Sym.: Base: Mods: FRow: Sym.2: Sett.: ARTSEY: ARTSEY num: ARTSEY sym: ARTSEY paren:...

A diagram of a 10-pin bowling rack. The pins are numbered F6 through F10. The center pin is labeled 'PRINTSCREEN'. There are two arrows pointing down from the center pin. At the bottom left, there are two squares, one white and one dark gray.

The diagram consists of 15 empty square boxes arranged in a staircase pattern. The top row has 5 boxes, the second row has 4 boxes, the third row has 3 boxes, the fourth row has 2 boxes, and the fifth row has 1 box. Below this main structure, there are 2 additional empty square boxes.

ARTSEY misc:

ARTSEY misc:

VOL UP

INS

MUTE

VOL DN

PSCRN

RSHFT sticky

ARTSEY misc

Sym.2

Sett.

ESC

TAB

BSPC

'

ENTER

ENTER

LCTRL sticky

LGUI sticky

LALT sticky

BACKSPACE

DELETE

LSHFT toggle

B

C

N

F

G

U

H

V

J

W

Urchin keymap – page 3 of 3

25 combo diagrams

