

Base:

QWERT

ASDCFG

ZXCVB

Mods

SPACE
LShift

YUIOP

HJKL

NM;P

SPACE

Sym.2
Sym.

12345

{}[]

\$%&')

ERow

Sym.2

67890

+*

@!"-./

<

Mods:

PREV PP NEXT PAUSE

ESC LGUI sticky LCTRL sticky Escaps_word

LALT sticky TAB

CTRL

PG UP HOME UP END

PG DN LEFT DOWN RIGHT

BSPC

DEL

ENTER

ERow

Sett.:

F2 F3 F4 F5

F1 LGUI sticky LCTRL sticky

LALT sticky

F6 F7 F8 F9 F10

F11 F12 PRINTSCREEN

Sym.2:

< > #

^ ~ \ | &

· ? :

ARTSEY:

T R A

S ARTSEY num I Y E

0 ARTSEY misc

ARTSEY toggle

SPACE

ARTSEY num:

3 2 1

ARTSEY num 6 5 4

ARTSEY paren:

()

{ []

}

ARTSEY paren

ARTSEY sym:

; \ !

· - ? ARTSEY sym

=

ARTSEY nav:

HOME UP END

PG UP LEFT DOWN RIGHT

PG DN

ARTSEY BT:

BT 2 BT 1 BT 0

OUT BLE BT 5 BT 4 BT 3

OUT USB

ARTSEY misc:

VOL UP INS MUTE

VOL DN PSCRN RSHFT sticky

ARTSEY misc

Combos:

Sym.2

Sett.

ESC

TAB

BSPC

,

ENTER

ENTER

LCTRL sticky

LGUI sticky

LALT sticky

BACKSPACE

DELETE

LSHFT toggle

B

C

N

F

G

U

H

V

J

W

K

,

.

/

!

7

8

9

0

ESC

ARTSEY nav toggle

M

D

P

Q

X

L

,

TAB

SPACE

LSHFT sticky

ARTSEY BT toggle

BT CLR

Z

CAPS