Table of Contents

• Kinect

• Joystick

• Localization and navigation

• Motor controller

| 1. Installation of Ubuntu on Skylab VM;s |
|--|
| Welcome |
| Project Willy |
| • History of Willy |
| • Project Willy |
| • Publicity |
| • Sponsors |
| Getting started |
| • Introduction to ROS |
| Development Guide |
| Driving Willy |
| • Manual |
| • Wiki Manual |
| Build of Willy |
| • Design history |
| • Hardware |
| Architecture |
| Software Architecture |
| • ROS topic design |
| Raspberry Pi's |
| • Sensor node |
| Social Interaction node |
| • Power node |
| Components |
| • ROS master |
| New ROS master on Lubuntu |
| • Sonar |
| • Lidar |

Lessons learned

- Todo & Advice
- · Lessons Learned

Archive

- Previous Groups
- Research Archive
- Skylab Architecture
- Skylab
- Multi master
- WillyWRT
- Realisation
- Hardware
- Brain
- Design Guild
- Social interaction
- Speech
- Speech recognition
- IMU
- Human Detection
- Radeffect App

1. Installation of Ubuntu on Skylab VM;s

The VM's Fetcher and Sylab ROS master have ROS installed. Run these commands on Ubuntu 16.04 to install ROS Kinetic ready to run.

```
sudo sh -c 'echo "deb http://packages.ros.org/ros/ubuntu $(lsb_release -sc) main" >
/etc/apt/sources.list.d/ros-latest.list'
sudo apt-key adv --keyserver hkp://ha.pool.sks-keyservers.net:80 --recv-key
421C365BD9FF1F717815A3895523BAEEB01FA116
sudo apt-key adv --keyserver hkp://keyserver.ubuntu.com:80 --recv-key
421C365BD9FF1F717815A3895523BAEEB01FA116
sudo apt-get update
sudo apt-get install ros-kinetic-desktop-full
apt-cache search ros-kinetic
sudo rosdep init
rosdep update
echo "source /opt/ros/kinetic/setup.bash" >> ~/.bashrc
source ~/.bashrc
sudo apt-get install python-rosinstall python-rosinstall-generator python-wstool
build-essential
mkdir -p ~/catkin_ws/src
cd ~/catkin_ws/
catkin_make
source devel/setup.bash
```

reference: http://wiki.ros.org/kinetic/Installation/Ubuntu