

Data Structures Algorithms Interview Preparation Topic-wise Practice C++ Java Python Competitive Program

Addressing Modes

Difficulty Level: Easy • Last Updated: 04 Sep, 2019

Addressing Modes- The term addressing modes refers to the way in which the operand of an instruction is specified. The addressing mode specifies a rule for interpreting or modifying the address field of the instruction before the operand is actually executed.

Addressing modes for 8086 instructions are divided into two categories:

- 1) Addressing modes for data
- 2) Addressing modes for branch

The 8086 memory addressing modes provide flexible access to memory, allowing you to easily access variables, arrays, records, pointers, and other complex data types. The key to good assembly language programming is the proper use of memory addressing modes.

An assembly language program instruction consists of two parts

Opcode Operand

The memory address of an operand consists of two components:

IMPORTANT TERMS

- Starting address of memory segment.
- Effective address or Offset: An offset is determined by adding any combination of three

We use cookies to ensure you have the best browsing experience on our website. By using our site, you acknowledge that you have read and understood our <u>Cookie Policy</u> & <u>Privacy Policy</u>

Login


Register

• Index: Content of index register SI or DI.

According to different ways of specifying an operand by 8086 microprocessor, different addressing modes are used by 8086.

Addressing modes used by 8086 microprocessor are discussed below:


• **Implied mode:** In implied addressing the operand is specified in the instruction itself. In this mode the data is 8 bits or 16 bits long and data is the part of instruction. Zero address instruction are designed with implied addressing mode.



Example: CLC (used to reset Carry flag to 0)

• Immediate addressing mode (symbol #):In this mode data is present in address field of instruction .Designed like one address instruction format.

Note:Limitation in the immediate mode is that the range of constants are restricted by size of address field.



Example: MOV AL, 35H (move the data 35H into AL register)

• **Register mode:** In register addressing the operand is placed in one of 8 bit or 16 bit general purpose registers. The data is in the register that is specified by the instruction.

Here one register reference is required to access the data

Login

Register



Example: MOV AX,CX (move the contents of CX register to AX register)

• **Register Indirect mode**: In this addressing the operand's offset is placed in any one of the registers BX,BP,SI,DI as specified in the instruction. The effective address of the data is in the base register or an index register that is specified by the instruction.

Here two register reference is required to access the data.



The 8086 CPUs let you access memory indirectly through a register using the register indirect addressing modes.

MOV AX, [BX](move the contents of memory location s addressed by the register BX to the register AX)

• Auto Indexed (increment mode): Effective address of the operand is the contents of a register specified in the instruction. After accessing the operand, the contents of this register are automatically incremented to point to the next consecutive memory location. (R1)+.

Here one register reference, one memory reference and one ALU operation is required to access the data.

Login

Register

R2 = R2 + d

• Auto indexed ('decrement mode): Effective address of the operand is the contents of a register specified in the instruction. Before accessing the operand, the contents of this register are automatically decremented to point to the previous consecutive memory location. -(R1)

Here one register reference, one memory reference and one ALU operation is required to access the data.

Example:

Add R1,
$$-(R2)$$
 //OR
R2 = R2-d
R1 = R1 + M[R2]

Auto decrement mode is same as auto increment mode. Both can also be used to implement a stack as push and pop. Auto increment and Auto decrement modes are useful for implementing "Last-In-First-Out" data structures.

• **Direct addressing/ Absolute addressing Mode (symbol []):** The operand's offset is given in the instruction as an 8 bit or 16 bit displacement element. In this addressing mode the 16 bit effective address of the data is the part of the instruction.

Here only one memory reference operation is required to access the data.



Example: ADD AL, [0301] //add the contents of offset address 0301 to AL

• Indirect addressing Mode (symbol @ or ()):In this mode address field of instruction contains the address of effective address.Here two references are required.

We use cookies to ensure you have the best browsing experience on our website. By using our site, you acknowledge that you have read and understood our Cookie Policy & Privacy Policy

Login

Register

register name will be maintained in the address field of an instruction.

Here one register reference, one memory reference is required to access the data.

- 2. Memory Indirect:In this mode effective address is in the memory, and corresponding memory address will be maintained in the address field of an instruction.
 - Here two memory reference is required to access the data.
- **Indexed addressing mode**: The operand's offset is the sum of the content of an index register SI or DI and an 8 bit or 16 bit displacement.

```
Example:MOV AX, [SI +05]
```

• **Based Indexed Addressing:** The operand's offset is sum of the content of a base register BX or BP and an index register SI or DI.

```
Example: ADD AX, [BX+SI]
```

Based on Transfer of control, addressing modes are:

• **PC relative addressing mode:** PC relative addressing mode is used to implement intra segment transfer of control, In this mode effective address is obtained by adding displacement to PC.

```
EA= PC + Address field value
PC= PC + Relative value.
```

• **Base register addressing mode:** Base register addressing mode is used to implement inter segment transfer of control. In this mode effective address is obtained by adding base register value to address field value.

```
EA= Base register + Address field value.
PC= Base register + Relative value.
```

Note:

- 1. PC relative nad based register both addressing modes are suitable for program relocation at runtime.
- 2. Based register addressing mode is best suitable to write position independent codes.

Advantages of Addressing Modes

1. To give programmers to facilities such as Pointers, counters for loop controls, indexing of

Login

Register

Match each of the high level language statements given on the left hand side with the most natural addressing mode from those listed on the right hand side.

- 1. A[1] = B[J];
- a. Indirect addressing
- 2. while [*A++];
- b. Indexed addressing
- **(A)** (1, c), (2, b), (3, a)
- **(B)** (1, a), (2, c), (3, b)
- **(C)** (1, b), (2, c), (3, a)
- **(D)** (1, a), (2, b), (3, c)

Answer: (C)

Explanation:

List 1 List 2

- 1) A[1] = B[J];
- b) Index addressing

Here indexing is used

- 2) while [*A++]; c) auto increment

The memory locations are automatically incremented

3) int temp = *x; a) Indirect addressing

Here temp is assigned the value of int type stored

at the address contained in X

Hence (C) is correct solution.

This article is contributed by **Pooja Taneja.** Please write comments if you find anything incorrect, or you want to share more information about the topic discussed above.

Interview Series Prepare for free
Every Sunday | 7 - 8:30 PM IST



Login

Register

Computer Organization | Problem Solving on Instruction Format

Machine Instructions

Page: 1 2

RECOMMENDED ARTICLES

- O1 Addressing modes in 8086 microprocessor 05 Addressing modes in 8085 microprocessor 18, May 18
- Difference between Memory based and Register based Addressing Modes
 29, Oct 18

 Difference between Direct and Immediate Addressing Modes
 06, Apr 20
- Difference between Direct and Implied
 Addressing Modes
 15, Jun 20

 Difference between Indirect and Immediate Addressing Modes
 06, Apr 20
- How to execute a 11-digit instruction using different addressing modes in Python?

 26, Oct 20

 Difference between PC relative and Base register Addressing Modes
 08, Apr 20

Article Contributed By:



Vote for difficulty

Current difficulty: Easy

Easy Normal Medium Hard Expert

Login

Register

Improve Article

Report Issue

Writing code in comment? Please use ide.geeksforgeeks.org, generate link and share the link here.

Load Comments



A–143, 9th Floor, Sovereign Corporate Tower, Sector–136, Noida, Uttar Pradesh – 201305

feedback@geeksforgeeks.org

Company

About Us

Careers

Data Structures

In Media

SDE Cheat Sheet

Contact Us

Machine learning

Privacy Policy

CS Subjects

Copyright Policy

Video Tutorials

Courses

We use cookies to ensure you have the best browsing experience on our website. By using our site, you acknowledge that you have read and understood our Cookie Policy & Privacy Policy

Login

Register

Top News
Technology
Work & Career
Business
Finance
Lifestyle

Web Development

Knowledge

Web Tutorials

Django Tutorial

HTML

JavaScript

Bootstrap

ReactJS

NodeJS

Contribute

Java

CPP

Golang

C#

SQL

Kotlin

Write an Article

Improve an Article

Pick Topics to Write

Write Interview Experience

Internships

Video Internship

@geeksforgeeks, Some rights reserved