

EDDF/FRA



JEPPesen

FRANKFURT/MAIN, GERMANY

29 NOV 24


10-8

FRANKFURT/MAIN

OPENING OF TWY S24, CLOSING OF TWY S23

REFER ALSO TO LATEST NOTAMS

TWY S23 closed.
New TWY S24 in operation and available for
ACFT with MAX wingspan up to 262' / 80m.



LEGEND



Construction area



Limit of Apron
competence area


EDDF/FRA

JEPPesen
23 MAY 25 (10-8A)

FRANKFURT/MAIN, GERMANY
FRANKFURT/MAIN

OPENING OF TWY S14
REFER ALSO TO LATEST NOTAMS

Twy S14 will be reopened and can be used by ACFT with a wingspan up to 262'/80m.



LEGEND

-  Construction area
-  Limit of Apron competence area
-  ② Numbered Break away areas for push-back operations
-  ① Unnumbered Break away areas for push-back operations


EDDF/FRA

JEPPESEN
29 NOV 24 (10-8B)

FRANKFURT/MAIN, GERMANY
FRANKFURT/MAIN

OPENING AND CLOSING OF STANDS NEAR J-PIER
REFER ALSO TO LATEST NOTAMS

Stands J13 and J17 will be opened.
Stands J7, J9 and J11 will be closed.
Stand J13 and J17 can be used by ACFT with a wingspan up to 118'/36m.



LEGEND

- Construction area
- Limit of Apron competence area
- ② Numbered Break away areas for push-back operations
- ① Unnumbered Break away areas for push-back operations

EDDF/FRA



JEPPesen

FRANKFURT/MAIN, GERMANY

2 MAY 25

10-8C


FRANKFURT/MAIN

OPENING AND CLOSING OF STANDS NEAR H-PIER

REFER ALSO TO LATEST NOTAMS

In May, stands H9, H11 and H13 will be opened and can be used by ACFT with a wingspan up to 118'/36m.

In June, stands H1, H3, H5 and H7 will be opened. Twy S8 will be extended towards the south and Twy S9 south of Twy S will be closed. ACFT Stands H1 and H7 can be used by ACFT with a wingspan up to 118'/36m. ACFT stands H3 and H5 can be used by ACFT with a wingspan up to 171'/52m.




LEGEND


- Construction area
- Limit of Apron competence area
- Numbered Break away areas for push-back operations


EDDF / FRA
Apt Elev 363'
N50 02.0 E008 34.2


JEPPESSEN
23 MAY 25 10-9

FRANKFURT / MAIN, GERMANY
FRANKFURT / MAIN









EDDF/FRA



JEPPESSEN FRANKFURT/MAIN, GERMANY

28 MAR 25 (10-9D)

FRANKFURT/MAIN

INS COORDINATES			
STAND No.	COORDINATES	STAND No.	COORDINATES
A1	N50 02.9 E008 34.3	F237	N50 02.3 E008 31.7
A11	N50 02.9 E008 34.2	F238	N50 02.2 E008 31.6
A13 thru A15	N50 02.9 E008 34.1	G1	N50 01.9 E008 35.0
A16	N50 02.8 E008 34.1	G2	N50 01.9 E008 35.1
A17	N50 02.9 E008 34.1	G3	N50 01.9 E008 35.0
A18	N50 02.8 E008 34.0	G4	N50 01.9 E008 35.1
A19	N50 02.8 E008 34.1	G5	N50 01.9 E008 35.0
A20	N50 02.8 E008 34.0	G6, G7	N50 02.0 E008 35.1
A21	N50 02.8 E008 34.1	G8	N50 02.0 E008 35.2
A22	N50 02.7 E008 34.0	G9	N50 02.0 E008 35.1
A23	N50 02.8 E008 34.0	G10	N50 02.1 E008 35.2
A24, A25	N50 02.7 E008 34.0	G11	N50 02.1 E008 35.1
A26 thru A30	N50 02.7 E008 33.9	G12, G13	N50 02.1 E008 35.2
A34, A36	N50 02.6 E008 33.8	G14	N50 02.1 E008 35.3
A38, A40	N50 02.6 E008 33.7	G15	N50 02.1 E008 35.2
A50, A52	N50 02.9 E008 33.9	G16	N50 02.2 E008 35.2
A54 thru A58	N50 02.9 E008 33.8	G16A	N50 02.2 E008 35.3
A58A	N50 02.8 E008 33.8	H2	N50 01.9 E008 34.9
A58B thru A62B	N50 02.8 E008 33.7	H4	N50 01.9 E008 34.8
A66 thru A69	N50 02.8 E008 33.6	H6, H8, H10	N50 02.0 E008 34.8
B10, B20	N50 02.9 E008 34.3	H12, H14	N50 02.1 E008 34.8
B22 thru B28	N50 02.8 E008 34.3	H701	N50 01.3 E008 31.9
B41 thru B43	N50 02.9 E008 34.5	J2A thru J2B	N50 01.9 E008 34.6
B44 thru B46	N50 02.9 E008 34.6	J4	N50 01.9 E008 34.5
B47	N50 02.8 E008 34.6	J5	N50 01.8 E008 34.6
B48	N50 02.9 E008 34.5	J6 thru J6B	N50 01.9 E008 34.5
C2, C4	N50 03.0 E008 34.5	J7	N50 01.8 E008 34.5
C5, C6	N50 03.0 E008 34.6	J8	N50 02.0 E008 34.4
C8, C11	N50 03.0 E008 34.7	J9	N50 01.8 E008 34.4
C13 thru C14S	N50 03.0 E008 34.8	J11, J13	N50 01.9 E008 34.3
C15 thru C15S	N50 03.0 E008 34.9	J17	N50 01.9 E008 34.2
C16 thru C16S	N50 03.0 E008 35.0	K2	N50 01.7 E008 34.7
D1	N50 03.1 E008 35.2	K4	N50 01.7 E008 34.6
D1A thru D4B	N50 03.0 E008 35.2	K6, K8	N50 01.6 E008 34.5
D5, D5A	N50 03.0 E008 35.1	K10	N50 01.6 E008 34.4
D8	N50 03.0 E008 35.0		
D8A	N50 03.0 E008 35.1		
E2 thru E2B	N50 03.1 E008 35.3		
E5 thru E6A	N50 03.1 E008 35.4		
E9, E9A	N50 03.1 E008 35.5		
F211	N50 02.4 E008 32.7		
F212	N50 02.4 E008 32.6		
F213, F214	N50 02.4 E008 32.7		
F215	N50 02.4 E008 32.9		
F216	N50 02.5 E008 32.9		
F221, F222	N50 02.3 E008 32.5		
F223	N50 02.3 E008 32.4		
F224, F225	N50 02.4 E008 32.4		
F231	N50 02.3 E008 32.1		
F232	N50 02.3 E008 32.0		
F232A	N50 02.2 E008 32.0		
F233	N50 02.3 E008 31.9		
F233A	N50 02.2 E008 32.0		
F234	N50 02.3 E008 31.8		
F235	N50 02.2 E008 31.8		

CHANGES: Stands J13 and J17 added.

EDDF/FRA




JEPPESSEN FRANKFURT/MAIN, GERMANY

28 MAR 25

10-9E

FRANKFURT/MAIN





CHANGES: Twy S24 established, part of twy S23 closed.

© JEPPESSEN, 2006, 2025. ALL RIGHTS RESERVED.

EDDF/FRA

JEPPESSEN FRANKFURT/MAIN, GERMANY
28 MAR 25 10-9E1
FRANKFURT/MAIN




EDDF/FRA

 **JEPPesen** FRANKFURT/MAIN, GERMANY
23 MAY 25 (10-9F) FRANKFURT/MAIN

ADVANCED VISUAL DOCKING GUIDANCE SYSTEM (A-VDGS)


DISPLAY OF IMAGES AND FUNCTIONS ON THE PANEL

Examples:



Safety Information:

- If a pilot is unsure of the information shown on the display the acft has to be stopped immediately and further information for clearance needs to be obtained.
- A pilot shall not enter the stand area unless the capture signal is displayed on the docking system and unless the acft type displayed matches the approaching acft.
- The pilot shall not proceed beyond the first passenger boarding bridge in sight unless the capture signal is superseded by the final lead-in information (distance to stop-point, stop-point, deviation indicator or steering direction, taxi guidance line, present acft position). The same applies in case the display shows "HOLD", "WAIT", "WAIT VIEW BLOCK", "WAIT GATE BLOCK", "WAIT ID FAIL" or "STOP".



Depending on the system type, displays can be slightly different or additional.