

MPK mini

Latest Firmware Version: 0.022 Release Date: July 16, 2014

Firmware Update Instructions

Important: Updating the firmware on your MPK mini will overwrite all Programs stored on it. If you want to save these, save them to your computer before following the steps below, and then send the Programs back to the MPK mini after the firmware update is complete. See the MPK mini *Editor User Guide* to learn how to do this.

- 1. Connect MPK mini to your computer's USB port.
- 2. Unzip the contents of **MPKmini2_Firmware_Updater.zip** to your Desktop.
- 3. Open the updater application:
 - Windows: Double-click the .exe file and follow the on-screen instructions.
 - Mac OS X: Double-click the MacUpdater application and follow the on-screen instructions.

Changes and Improvements

- Corrects internal clock rate to better sync with applications.
- Fixes issue where Note Off message was not sent if a key or pad was released after an octave shift.

Technical Support

For additional help, visit akaipro.com/support.