



INSTRUCTIONS:

- 1. Remove and discard C18.
- 2. Remove and replace R16 with 120 ohms (same as R6)