



Knowledge for a First New Install

Generated on: 21 October 2025

Contents

- Knowledge for a First New Install 3
 - Prerequisites 3
 - Support Email Template..... 3
 - Preparation 4
 - On Site Documentation Review 4
 - Installation Preparation..... 5
 - Articles..... 5
 - Notes..... 5
 - Installation 6
 - Post Install..... 7
 - Customer Follow-up 7

Knowledge for a First New Install

New Install (Single System)

If you have any questions, please reach out to the Pure Storage account team.

Prerequisites

Pre-Install Checklist

Download this Pre-install checklist spreadsheet and review it with your customer. The checklist helps customers prepare their site. Please put the AE/SE from Pure on cc when you are emailing your customer.

This document is for a single array install.

Please review with the customer what contacts they want, and how Pure support should reach out to them. Questions that you should ask your customer and report to the account team:

1. Do they have a function like infra@customer.com that they want the emails to come to?
2. Specific people that maybe need cc on the support email?
3. How should we tag people in our internal system? Technical, Manager, Sales etc.?
4. Is this a dark site?
5. Do we need to have any special handling instructions?
6. Who will be Pure1 admin?

**Note:**

A minimum of two weeks before going to the customer site, please send an email to support@purestorage.com telling them that the install is coming up.

Support Email Template

**Partner - Partner Note**

Suggested template:



"Hello Pure Support. My name is NAME, and I will do a new install of a Flasharray at customer CUSTOMER. I will be there at this date 202-*-*-** between 9-12 I would like to have a support agent that can do Health checks and if I'm in need of any assistance, I would like to know who to reach out to.*

This is my email: EMAIL This is my phone number: PHONE NUMBER."

Tip: If the customer is a VMware customer you would also like to include "Please upgrade HTML5 plugin to the latest available GA" in that support case. If you want to use the internal one. The external OVA you can find further down in this document.

If support@purestorage.com is not responding, please send an email to case-escalation@purestorage.com with the case number.

To call, use this list of international numbers: [Contact Us](#)

Please also share the international numbers and the email for escalation to the customer.

Preparation

Please make sure you have the following before going to the customer:

- Support case number
- Enterprise Ready release of Purity firmware (not mandatory) this should be on a FAT32 formatted USB stick minimum 4GB.
- If you are using 6.3 or above then 6GB+ USB with with ExFAT, NTFS, EXT2, EXT3.
- Documentation on how to install FlashArray (or this document).
- Confirm with the account team that the customer is set-up in Pure internal systems according to your interview with the customer.
- Instructions to connect a laptop to a Pure FlashArray; [Console.pdf](#).
- Basically 115200 baud 8 bits, No Parity, 1 stop bit.
- Optional: Connect monitor and USB typing board (note that clipboard operations will not work).

On Site Documentation Review

After installation and with the customer, review the GUI and PURE1 and explain the basics. (This demo can be done remotely if needed). Also present the cellphone app. What we also want to share with your

customers is some pages where they can find information.

Review the following documentation with the customer:

- [Pure Storage Customer Support Guide](#)
- [Contact Us](#)
- Knowledge Base
- [Solutions](#)

Installation Preparation

Note that you don't have to connect cables to the array. It can be installed on your desk without anything connected. After the installation you can move it to the data center.

Articles

- Quick Installation Guide: [FlashArray//XR2 and //XR3 Quick Installation Guide](#)
- Quick Installation Guide: [FlashArray//XR4 Quick Installation Guide](#)
- More Information About Puresetup: [Purity User Info: puresetup](#)
- FAT32 (for version below 6.1 if you are running 6.3 and greater, the USB has to be 6GB+, so mandatory with ExFAT, NTFS, EXT2, EXT3, EXT4) [FlashArray Installation: Changing Purity//FA Version on a New FlashArray](#)

Notes

Note:

Please make sure to reboot the controllers before running "puresetup newinstall" if you have upgraded the system. This upgrade procedure is ONLY if the system is not installed. If the system is installed already or in production, you MUST use another procedure and files. Do NOT attempt to upgrade the system with purity_version.PPKG if it's already installed or in production.

This upgrade can be a good exercise to do this after install. It tests support + all the connectivity to ascertain that everything is working like expected.

Installation

Use the Pre-Install Checklist that you prepared before going to the datacenter as you go through these steps.

1. Connect the console to CT0 that is the TOP controller and get prompt.
2. Enter puresetup.
3. Copy and paste this password:

```
embind anecdota praiser obelize
```

4. Run:

```
hardware_check.py
```



Note:

//XR4 models run: `cobalt_check.py`.

5. Inspect the script results and make sure the results are satisfactory.
6. If this is a **XR4** model and the commands fail, there might be ongoing Firmware upgrades in the background. Do not pull the power or reboot. Let the firmware upgrades finish and then try again. This can take about 20 minutes.
7. Run:

```
puresetup newarray --skip-connectivity-tests
```



Note:

--skip skips some connectivity tests that take some time to fail if the array can't access the internet. With live internet then it's recommended not to add the --skip flag.

1. Possible NVME firmware upgrades may take a couple of minutes.
2. If prompted: Configure Rapid Data Locking? Select **No** in 99.9% of cases.
3. The installation will ask you to type continue and hit enter. Type **CONTINUE**.
4. Wait on a reply. Press ENTER again if nothing happens after 3 minutes.
5. Enter all the configuration parameters.
6. Prompt: "Would you like to save this configuration?" Select **YES**, if everything is correct.

7. Change your time zone.
8. The system kicks off an automatic restart.
9. In case it asks you for "Set new password" do that. (The old user is pureuser).
10. **MOVE THE CABLE** to CT1 (the bottom controller).
11. Prompt: puresetup
12. Copy paste this password:

```
embind anecdota praiser obelize
```

13. On the new line on the second controller, run:

```
puresetup secondary --skip-connectivity-tests
```

14. Some of the configuration will now get pulled from the first controller.
15. Enter the specific configuration that is needed for the second controller.
16. You may be prompted: "Set new password". The old password is pureuser.
17. Change the time zone and reboot.
18. You are all done. Congratulations. If you are looking for the user it's also pureuser.
19. **Note:** email the array name to Pure Storage SE/AE so that person can connect the array in Pure's internal system (so it shows up in Pure1 for the customer).

Post Install

- Make sure support does a health check (as you booked before going to the customer).
- Reach out to support and brief them that all was good. Remote assist is now enabled and that they can proceed with putting the array in to "Production ready".
- (Optional) remind them of the HTML5 plugin for vCenter if the customer is running VMware. There is an older on array version that works for some. But the newest can be found here: [Release Notes: Pure Storage Plugin for the vSphere Client](#).
- [Microsoft Platform Guide](#)
- If replication is needed, reach out to support and have them configure this.

Customer Follow-up

- Continue with the education that they might need from you or the Pure account team.
- Call the customer one week after you have been on site to check up. It's called POST sales =).

© 2015-2025 Pure Storage® ("Pure"), Portworx® and associated its trademarks can be found here as and its virtual patent marking program can be found here. Third party names may be trademarks of their respective owners. The Pure Storage products and programs described in this documentation are distributed under a license agreement restricting the use, copying, distribution, and decompilation/reverse engineering of the products. No part of this documentation may be reproduced in any form by any means without prior written authorization from Pure Storage, Inc. and its licensors, if any. Pure Storage may make improvements and/or changes in the Pure Storage products and/or the programs described in this documentation at any time without notice. This documentation is provided "as is" and all express or implied conditions, representations and warranties, including any implied warranty of merchantability, fitness for a particular purpose, or non-infringement, are disclaimed, except to the extent that such disclaimers are held to be legally invalid. Pure shall not be liable for incidental or consequential damages in connection with the furnishing, performance, or use of this documentation. The information contained in this documentation is subject to change without notice.
