# **Driver Vision Documentation**

### Team 4145

### Setup

- 1. Open Driver Station from desktop icon or start menu
- 2. Set the camera selection to "No Camera Selected" on the dashboard
- 3. Open "stream.html" from desktop icon or Chrome bookmark bar
- 4. Move the Chrome window to second monitor and make full-screen

### Commands

- The drive camera can be reversed by pressing button 3
- The gyro PID turn can be enabled by holding button 7
  - The vision camera marks the desired target with a red crosshair
  - When the crosshair is present, the robot will attempt to turn towards the target
  - o If there is no red crosshair, then the robot will not turn

## **Troubleshooting**

- If the vision stream is frozen or not present, refresh the Chrome window
- If the gyro PID turning is not working, tell Mark and/or Phillip what the exact issue is (e.g. overshooting, undershooting, oscillating, chattering, etc.)
- If the camera switching is not working, tell Mark and/or Phillip