

# The 10 Most Common Wrap Mistakes

And how to avoid them — from Wrap911

## ***1. Skipping full decontamination***

Wax, silicone and road film kill adhesion. Wash, degrease, clay, then IPA wipe every panel.

## ***2. Wrapping a cold or damp surface***

Below ~60°F adhesive won't flow. Warm the shop and dry seams and gaps completely.

## ***3. Wrong squeegee angle***

Keep the squeegee low and overlap each stroke by half to avoid lines and trapped air.

## ***4. Overstretching the film***

Stretched vinyl wants to shrink back. Use slack and heat, not force.

## ***5. Bridging deep channels***

Never stretch across a channel cold. Relieve the film and lay it in.

## ***6. Skipping post-heat***

Unheated film lifts in recesses, edges and rivets. Post-heat to manufacturer temperature.

## ***7. Poor rivet technique***

Relieve, press with a rivet brush, then post-heat each rivet.

## ***8. No edge wrap-around***

Wrap edges 1/4 in. or more where possible, then heat to lock them.

## ***9. Cutting on paint***

Use knifeless tape or a light blade touch. One paint cut can cost a repaint.

## ***10. No final inspection***

Walk the vehicle with a light. Fix bubbles and lifts before the customer does.

**Practice every one of these risk-free in Wrap911.** Download free on iOS and web.