
STANDARD DEPARTURE CHART RNAV (GNSS) -INSTRUMENT (SID)

TWR 118.6 / 118.25 APP 120.3 124.05 ACC 133.8 TRANSITION ALTITUDE 11 000ft

D-ATIS AP ID-WSSS 128.6 SINGAPORE/Singapore Changi RWY 02C MERSING DEPARTURES VMR 6A



VMR 6A (SID) RNAV GNSS RWY 02C - DESCRIPTIONS

Formal & Abbreviated Descriptions

Formal Description	Abbreviated Description	Path Terminator	Fly-Over required
To MOXIB on course 023° at or above 2000ft, turn left.	MOXIB [M023; A020+; L] -	CF	N
To AKOMA at or above 7000ft, turn right.	AKOMA [A070+; R] -	TF	N
To VMR.	VMR	TF	N

Tabular Descriptions

Path Term	Waypoint Name	Fly-Over	Course °M(°T)	Distance (NM)	Turn Direction	Altitude	Speed Limit	Navigation Spec
CF	MOXIB	-	023(023.4)	8.0	L	A020+	-	RNAV1
TF	AKOMA	-	331(331.4)	18.0	R	A070+	-	RNAV1
TF	VMR	-	356(356.4)	38.0	1	-	-	RNAV1

Radio Communications Failure Procedure					
1	SET TRANSPONDER TO MODE A/C CODE 7600				
2	COMMUNICATIONS FAILURE OCCURS IMMEDIATELY AFTER DEPARTURE:				
	PROCEED DIRECT TO NYLON HOLDING AREA (NHA) CLIMBING TO THE LAST ASSIGNED				
	ALTITUDE, THEREAFTER REFER TO SINGAPORE AIP ON RADIO COMMUNICATIONS FAILURE				
	PROCEDURE.				