
STANDARD ARRIVAL CHART RNAV (GNSS) -INSTRUMENT (STAR)

ACC 133.25 APP 124.6 119.3 TWR 118.6 / 118.25 TRANSITION ALTITUDE 11 000ft

D-ATIS AP ID-WSSS ARR 128.025

SINGAPORE/Singapore Changi RWY 02L/C/R TEBUN ONE ALPHA ARRIVAL TEBUN 1A



TEBUN 1A (STAR) RNAV GNSS RWY 02L/02C/02R - DESCRIPTIONS

Formal & Abbreviated Descriptions

Formal Description	Abbreviated Description	Path Terminator	Fly-Over required
From TEBUN, Speed 250kts.	TEBUN [K250] -	IF	N
To VAMPO at or above 10000ft, speed 220kts, turn left.	VAMPO [A100+; K220; L] -	TF	N
To IBASU, turn left.	IBASU [L] -	TF	N
To VEXEL, turn left.	VEXEL [L] -	TF	N
To SAMKO at or above 4000ft, speed 190kts.	SAMKO [A040+; K190]	TF	N

Tabular Descriptions

Path Term	Waypoint Name	Fly-Over	Course °M(°T)	Distance (NM)	Turn Direction	Altitude	Speed Limit	Navigation Spec
IF	TEBUN	•	-	-	-	-	K250	RNAV1
TF	VAMPO	-	149(149.4)	19.0	L	A100+	K220	RNAV1
TF	IBASU		094(094.4)	9.0	L	-	-	RNAV1
TF	VEXEL	•	082(082.4)	9.0	L	-	-	RNAV1
TF	SAMKO	-	057(057.4)	12.0	-	A040+	K190	RNAV1

Radio Communications Failure Procedure

1	SET TRANSPONDER TO MODE A/C CODE 7600				
2	When cleared via TEBUN 1A by Singapore ATC				
	(a)	Maintain last assigned flight level or altitude and proceed on TEBUN 1A to SAMKO			
	(b)	From SAMKO commence descent and carry out appropriate landing procedure for			
		RWY 02 as close as possible to EAT or ETA			
	(c)	If unable to effect a landing, refer to Singapore AIP for missed approach procedure			
3	No clearance or instruction received from Singapore ATC				
	-	Refer to Singapore AIP for radio communications failure procedure			