Table 1: Denavit-Hartenberg Parameters

Link	$\alpha_{(i-1)}$	$a_{(i-1)}$	d_i	$ heta_i$
1	0	0	L_1	$\overline{q_1}$
2	$\frac{\pi}{2}$	L_2	0	$q_2 - \frac{\pi}{2}$
3	$\bar{0}$	L_3	0	q_3
4	$-\frac{\pi}{2}$	L_4	L_5	q_4
5	$\frac{\pi}{2}$ $-\frac{\pi}{2}$	0	0	q_5
6	$-\frac{\pi}{2}$	0	0	q_6
G	0	0	L_6	0

 cm

$$L_1 = 0.33 + 0.42 = 0.75 \,\mathrm{m}$$

$$L_2=0.35\,\mathrm{m}$$

$$L_3=1.25\,\mathrm{m}$$

$$L_4 = -0.054 \,\mathrm{m}$$

$$L_5 = 0.96 + 0.54 = 1.5 \,\mathrm{m}$$

$$L_6 = 0.193 + 0.11 = 0.303 \,\mathrm{m}$$