

User Manual

Dot-Pattern PC Hard Shell Case for MacBook Air 13 M1 A2337 A2179 A1932

Brand: BLHMCASE

Package Contents

- Top shell ×1 - Bottom shell ×1

Confirm Your MacBook Model (IMPORTANT!)

⚠ Please check the model number printed on the bottom of your MacBook before installation. This case is ONLY compatible with A2337 A2179 A1932 model. If the model number does not match, the case will not fit properly.

Installation Instructions

1. Locate 4 clips on the top cover and 6 clips on the bottom cover.
2. Align the hinge position first, attach the bottom cover and lock the 2 rear clips.
3. Gently press and snap the two front clips of the bottom cover into place.
4. Align the top cover with your MacBook, press lightly until you hear a click sound.
Installation is complete.



Removal Instructions

1. Keep your laptop screen open.
2. Gently pry open the corner clips and remove the top cover first.
3. Release the clips of the bottom cover and take off the bottom shell.

⚠ Warning: Do not force-bend the case. Excessive force may crack the shell or scratch your laptop.

Product Features

- Material: High-strength PC hard plastic, slim-fit design
- Heat dissipation: Vent slots on the bottom for proper heat ventilation
- Screen opening: Supports up to 120° opening without hinge interference
- Protection: Defends against daily scratches and minor bumps
- Appearance: Printed polka-dot pattern with good color fastness

Troubleshooting

Cannot fit the case

1. Double-check the model number on your MacBook bottom to confirm compatibility.
2. Make sure all clips are fully opened. Do not apply heavy force.
3. Verify top and bottom shells are not reversed.

Screen cannot close fully

1. Ensure all clips are securely snapped and no edges are warped.
2. Check for debris trapped between the case and laptop.

Hard to remove

Release clips one-by-one starting from corners. Do not pry hard at a single point.

Notice

1. This case offers protection against scratches and minor daily bumps. It does NOT protect against heavy impact or high-altitude drops.
2. Do not use sharp tools for installation or removal to avoid scratches.
3. Periodically take off the case and clean dust to prevent abrasion to your laptop body.