

Follow_Line_SW_NXT.basic*
main_call
portId
light_intensity
get_light_intensity*
left_motor_power
light_intensity
follow_line*
right_motor_power
state
power
portNb
set_left_motor_power*
brake
left_wheel_port*
left_wheel_brake*
power
portNb
set_right_motor_power*
brake
right_wheel_port*
right_wheel_brake*
state