Provide 2-ft Paved Shoulders (Both Sides)



2-ft paved shoulders add narrow recovery space along rural roads to reduce run-off-road crashes and improve edge safety.

Implementation Strategy

How and Where to Apply

- 2-ft paved shoulders are commonly used on rural two-lane roads with narrow or no shoulders.
- They are especially effective on segments with high run-off-road crash rates or roadside hazards.
- According to the **AASHTO** Roadside Design Guide, narrow shoulders can still provide safety benefits when full-width shoulders are not feasible.

Use in a Safe System Approach

This treatment supports Safer Roads and Safer Vehicles by increasing recovery space and reducing crash severity. It helps compensate for common driver errors like distraction or overcorrection, making rural roads more forgiving. On corridors with higher speeds and limited recovery zones, 2-ft paved shoulders can significantly reduce the risk of serious roadway departure crashes.

Key Stakeholders

Proactive Implementation

2-ft paved shoulders can be proactively added during resurfacing or preservation projects on rural roads with run-off-road or edge-related crash histories. A systemic approach can help identify segments with narrow lanes, steep edge drop-offs, or limited clear zones. Where full-width shoulders are not feasible, this treatment offers costeffective safety benefits. Including it in maintenance programs allows agencies to improve safety incrementally across the network.

Countermeasure Overview

Objective: Keep vehicles from encroaching on the roadside

Strategy: Apply shoulder treatments (Widen and/or pave shoulders)

Cost: \$ (Moderate)

Service Life: 20 years

State and county highway agencies Pavement and safety engineers

FACILITY

Run-off-road

Reduced visibility

Driver inattention



CONTRIBUTING

FACTORS

CRASH

Not specified



Rural

Safety Linkage

Targeted Solution



Run-Off-Road



Safer Infrastructure

Safe Roads



SAFE SYSTEM

Tier 1

2-ft paved shoulders. Source: Shoulder

Selected Related Countermeasures



Safety edge paving



Rumble strips along shoulder edge



Widening full-width shoulders where feasible

Reduce run-off-road crashes on rural roads.1



Reduce run-off-road crashes on rural roads²

¹ CMF ID: 10415

² CMF ID: 10414



afety Benefits

- FHWA. Low-Cost Safety Improvements for Rural Roads
- FHWA Proven Safety Countermeasures
- AASHTO Roadside Design Guide

