Universitatea Tehnică a Moldovei Facultatea Calculatoare Informatică și Microelectronică Departamentul Ingineria Software și Automatică

RAPORT

Lucrarea de laborator nr. 6.2 La disciplina "Internetul Lucrurilor"

Tema: Automate Finite - Semafor

A efectuat: st. gr. SI-211 A verificat:

Adrian Chihai Valentina Astafi

Chişinău – 2024

1 Definire Problemă

Sa se realizeze o aplicatie ce va implementa Automatele finite dupa cum urmeaza:

1. Proiectare Automat Finit aplicatie Semafor.

2 Descrierea funcțiilor programului

Funcțiile principale care sunt utilizate sunt: setup() - utilizată pentru inițializarea LED-urilor și a seriei și loop() - utilizată pentru a emite starea curentă, a întârzia un timp și a schimba starea pe baza stării curente. În figuria 2.1 este tabelul de tranziție pentru automatul finit, iar în figura 2.2 - diagrama acestuia.

Number	Current state	Next State for T
1	goS	waitS
2	waitS	goW
3	goW	waitW
4	waitW	goS

Fig. 2.1. Tabel de tranziție pentru semafor

Următoarea figură este diagrama de stări pentru semafor:




Fig. 2.2. Diagrama pentru semafor

Figura 2.3 reprezintă funcția setup din program.




Fig. 2.3. Funcția setup

Figura 2.4 prezintă logica implementată în funcția de buclă a programului buton-LED.




Fig. 2.4. Funcția de loop pentru semafor




Fig. 2.5. setOutput function

3 Circuitul elaborat

Figura 2.6 reprezintă schema electrică asamblată a circuitului semafor :




Fig. 2.6. Circuitul elaborat semafor În figura următoare este rulat circuitul semafor.




Fig. 2.7.Circuitul semafor rulat

Concluzie

În cadrul acestui laborator, am aplicat cunoștințele despre automatele finite, dezvoltând un sistem funcțional pentru controlul unui semafor. Am utilizat structuri de date pentru a gestiona tranzițiile între stări și a asigura un flux logic al aplicației. Prin integrarea LED-urilor și a butoanelor, am implementat tranziții între stările "Go", "Wait" și "Stop", simulând comportamentul real al unui semafor.

Implementarea funcției SetOutput a simplificat controlul LED-urilor, iar utilizarea tabelei de stări a făcut sistemul ușor de extins. Acest laborator a consolidat înțelegerea automatelor finite și aplicarea lor practică, oferind o bază pentru proiecte mai complexe în domeniul Internetului Lucrurilor.

Anexa 1

```
#define BAUD RATE 9600
#define SOUTH STATE HIGH
#define WEST STATE HIGH
#define WEST_GREEN_PIN 8
#define WEST YELLOW PIN 9
#define WEST_RED_PIN 10
#define SOUTH GREEN PIN 11
#define SOUTH_YELLOW_PIN 12
#define SOUTH RED PIN 13
#define NONE REQ 0b00
#define SOUTH REQ 0b01
#define WEST REQ 0b10
#define BOTH REQ 0b11
#define GO SOUTH_STATE 0
#define WAIT SOUTH STATE 1
#define GO WEST_STATE 2
#define WAIT WEST STATE 3
#define GO_SOUTH_OUT 0b100001
#define WAIT SOUTH OUT 0b100010
#define GO WEST OUT 0b001100
#define WAIT_WEST_OUT 0b010100
#define GO SOUTH DELAY 3000
#define WAIT_SOUTH_DELAY 1000
#define GO WEST DELAY 3000
#define WAIT WEST DELAY 1000
#define RED TO GREEN YELLOW DELAY 1000
#define BLINK_DELAY 500
#define BLINK_COUNT 3
struct State {
 unsigned long Out; // 6-bit pattern to output
 unsigned long Time; // delay in 10ms units
 unsigned long Next[4]; // next state
};
typedef const struct State STyp;
STyp FSM[4]={
 {GO_SOUTH_OUT, GO_SOUTH_DELAY, {GO_SOUTH_STATE, WAIT_SOUTH_STATE, GO_SOUTH_STATE,
WAIT SOUTH STATE }},
```

```
{WAIT_SOUTH_OUT, WAIT_SOUTH_DELAY, {GO_WEST_STATE, GO_WEST_STATE, GO_WEST_STATE,
GO_WEST_STATE }},
  {GO_WEST_OUT, GO_WEST_DELAY,{GO_WEST_STATE, GO_WEST_STATE, WAIT_WEST_STATE,
WAIT_WEST_STATE }},
  {WAIT_WEST_OUT, WAIT_WEST_DELAY, {GO_SOUTH_STATE, GO_SOUTH_STATE, GO_SOUTH_STATE,
GO_SOUTH_STATE }}};
int FSM_State = GO_SOUTH_STATE;
int GetInput(void) {
 int southButton = SOUTH STATE;
  int westButton = WEST_STATE;
  if (southButton && westButton)
    return BOTH_REQ;
  else if (westButton)
    return WEST_REQ;
  else if (southButton)
   return SOUTH_REQ;
    return NONE_REQ;
void SetOutput(int out) {
  int ledState;
  ledState = (out & (1 << 5)) ? HIGH : LOW;</pre>
  digitalWrite(WEST_RED_PIN, ledState);
  ledState = (out & (1 << 4)) ? HIGH : LOW;</pre>
  digitalWrite(WEST_YELLOW_PIN, ledState);
  ledState = (out & (1 << 3)) ? HIGH : LOW;</pre>
  digitalWrite(WEST_GREEN_PIN, ledState);
  ledState = (out & (1 << 2)) ? HIGH : LOW;</pre>
  digitalWrite(SOUTH_RED_PIN, ledState);
  ledState = (out & (1 << 1)) ? HIGH : LOW;</pre>
  digitalWrite(SOUTH_YELLOW_PIN, ledState);
  ledState = (out & (1 << 0)) ? HIGH : LOW;</pre>
  digitalWrite(SOUTH_GREEN_PIN, ledState);
void setup() {
  Serial.begin(BAUD_RATE);
  pinMode(WEST GREEN PIN, OUTPUT);
  pinMode(WEST_YELLOW_PIN, OUTPUT);
  pinMode(WEST_RED_PIN, OUTPUT);
  pinMode(SOUTH_GREEN_PIN, OUTPUT);
  pinMode(SOUTH_YELLOW_PIN, OUTPUT);
  pinMode(SOUTH_RED_PIN, OUTPUT);
  FSM_State = GO_SOUTH_STATE;
```

```
void loop() {
  int FSM_Output = FSM[FSM_State].Out;
 SetOutput(FSM_Output);
 delay(FSM[FSM_State].Time);
  if (FSM_State == WAIT_SOUTH_STATE || FSM_State == WAIT_WEST_STATE) {
   digitalWrite(WEST_YELLOW_PIN, HIGH);
    digitalWrite(SOUTH_YELLOW_PIN, HIGH);
    delay(RED_TO_GREEN_YELLOW_DELAY);
    digitalWrite(WEST_YELLOW_PIN, LOW);
    digitalWrite(SOUTH_YELLOW_PIN, LOW);
  if ((FSM_State == GO_WEST_STATE && (FSM_Output & (1 << 3))) ||</pre>
      (FSM_State == GO_SOUTH_STATE && (FSM_Output & (1 << 0)))) {</pre>
    for (int i = 0; i < BLINK_COUNT; i++) {</pre>
      digitalWrite(FSM_State == GO_WEST_STATE ? WEST_GREEN_PIN : SOUTH_GREEN_PIN,
HIGH);
      delay(BLINK_DELAY);
      digitalWrite(FSM_State == GO_WEST_STATE ? WEST_GREEN_PIN : SOUTH_GREEN_PIN, LOW);
      delay(BLINK_DELAY);
    }
  int FSM_Inputs = GetInput();
  FSM_State = FSM[FSM_State].Next[FSM_Inputs];
```