#### **Essentials of MOSFETs**

# Unit 4: Transmission Theory of the MOSFET

# Lecture 4.1: The Landauer Approach

#### **Mark Lundstrom**

Iundstro@purdue.edu
Electrical and Computer Engineering
Purdue University
West Lafayette, Indiana USA




#### Introduction

The Landauer Approach is a simple and very physical way to describe electron transport from the ballistic to diffusive limits (i.e. from short to long channel MOSFETs).

Our description of this approach will be very simple and intuitive. Those who want a deeper understanding, should consult:


Supriyo Datta, *Lessons from Nanoelectronics*, 2<sup>nd</sup> Ed., Part A: Basic Concepts, World Scientific Publishing Co., Singapore, 2017.

#### Current in a nano device




How does the current that flows in contact 2, depend on the voltages on the two contacts?

#### Current




Can be derived from rigorous transport theory (the Boltzmann equation), but this expression is intuitively easy to understand.

#### What is transmission?




# Transmission (ballistic)



ballistic transport:  $\mathcal{T}=1$ 

# Transmission (diffusive)



# Transmission (general)

$$\mathcal{T}(E) = \frac{\lambda(E)}{\lambda(E) + L}$$

λ is the "mean-free-path for backscattering"


This expression can be derived with relatively few assumptions.

1) Diffusive: 
$$L \gg \lambda$$
  $\mathcal{T} = \frac{\lambda}{L} << 1$ 

2) Ballistic: 
$$L \ll \lambda$$
  $\mathcal{T} = 1$ 

$$\lambda(E) \neq \upsilon(E) \tau(E) = \Lambda$$


## MFP for backscattering in 1D



If we assume that the scattering is *isotropic* (equal probability of scattering forward or back) then average time between **backscattering** events is 2 |.


$$\lambda(E) = 2\nu(E)\tau(E)$$
  $\{\Lambda(E) = \nu(E)\tau(E)\}$ 

#### What is a channel?



(channels are also called "modes")

# Channels are like lanes on a highway




**Purdue University** 

# Channels (modes) from E(k)


# A channel is a state with a velocity.


$$M(E) = \frac{h}{4} \langle v_x^+(E) \rangle D_{1D}(E)$$



(Easily generalized to arbitrary band structures in 2D and 3D.)

# DOS(E) vs. M(E) (parabolic bands)





### Transmission, channels, and MFP

$$\mathcal{F}(E) = \frac{\lambda(E)}{\lambda(E) + L}$$

For two-dimensional electrons (i.e. in the channel of a MOSFET):

$$M(E) = W \frac{\sqrt{2m^*(E - E_C)}}{\pi\hbar}$$


$$M_{2D}(E) = M(E)/W$$

Parabolic bands + large structures with many channels.

$$\lambda(E) = \frac{\pi}{2} \Lambda(E)$$
$$\Lambda(E) = \upsilon(E) \tau(E)$$


$$\Lambda(E) = \upsilon(E)\tau(E)$$

#### Fermi window




The range of energies over which  $(f_1 - f_2) \neq 0$ 

# How current flows (T = 0 K)




# Summary



$$I = \frac{2q}{h} \int \mathcal{T}(E) M(E) (f_1 - f_2) dE$$

Can be used to describe the current in small and large devices and in short to long devices.

### Next topic



$$I_{DLIN} = \frac{W}{L} \mu_n C_{ox} (V_{GS} - V_T) V_{DS} \rightarrow ?$$