****Automated Microphone GUI Instructions****

Read this document to learn how to use the GUI for the automated microphone project

To start GUI run test:

Automic->python-server->testing->test_app.py

Once GUI opens in pop up window perform calibration




Figure 1. GUI Home Page

Calibration Process

To calibrate Microphone:

- 1. Select microphone for calibration
- 2. Push "Calibrate" button. A window as shown below will open




Figure 2. Calibration Window

- 3. Type in the inital x,y,z coordinates for the microphone into the respective "Initial Position" windows
- 4. Hit the "Record" button underneath the newly entered coordinates
- 5. While keeping the position recording window open, push the "Motor controls" button in the main GUI window. A window like the one show below should open.




Figure 3. Motor Control Window

- 6. Choose another position to move the microphone within its area of operation
- 7. Use the newly opend motor control window to move the microphone to this new position by adjusting each individual motor
- 8. Once the microphone is in the desired location, go back to the calibration window
- 9. Measure the microphones new coordinates and enter them into the respective "Final position" window
- 10. Hit the record button underneath
- 11. The system is now calibrated

Moving a Microphone

Calibrate system before attempting this. Only start this process if the system was calibrated and shutdown properly beforehand.

- 1. Select the desired microphone to move
- 2. Use the "Step size" slider to adjust to the desired moving interval
- 3. Use the motion buttons in the main GUI to move the microphone to the desired location

Saving a Preset

Follow the steps in the "Moving a Microphone" section before this

1. Once the microphone(s) are in the desired location, press the "Save" button in the main GUI, a new window should open below to name the preset.




Figure 4. Save Preset Window

- 2. To move the microphone to a desired preset, select the desired preset from the available presets
- 3. Press the "Recall" button
- 4. To home the microphone, press the "Home" button