

## **E220 Instrumentation and Control System**

2018-19 Semester 2

Dr. Qing Liu

Email: qing.liu@xjtlu.edu.cn

Office: EE516

Department of Electrical and Electronic Engineering

9 May, 2019

# Lecture 22

#### **Outline**


#### Frequency Response Methods

- ☐ Introduction
- □ Frequency Response Plots Polar Plot & Bode Plot
- ☐ Frequency Response Measurements
- □ Performance Specifications in the Frequency Domain
- ☐ Gain Margin and Phase Margin
- □ Compensators
- ☐ Frequency Response Methods Using Matlab


### Frequency Response Measurement

- A sine wave can be used to measure the open-loop frequency response of a system. In practice, a plot of amplitude versus frequency and phase versus frequency will be obtained. From these two plots, the transfer function (including both the loop TF and the closed-loop TF) of the system can be deduced.
- A device called a wave analyzer can be used to measure the amplitude and phase variations as the frequency of the input sine wave is altered. Also, a device called a transfer function analyzer can be used to measure the loop transfer function and closed-loop transfer function.
- A typical signal analyzer instrument can perform frequency response measurement from DC to 100 kHz. Built-in analysis and modeling capabilities can derive poles and zeros from measured frequency responses or construct phase and magnitude responses from user-supplied models. This device can also synthesize the frequency response of a model of a system, allowing a comparison with an actual response.

#### Example 22.1



Frequency (rad/s)




- The magnitude declines at about -20 dB/decade as  $\omega$  increase between 100 and 1000; and because the phase is -45° and the magnitude is -3dB at 300 rad/s  $\rightarrow$  there must be a pole at  $p_1 = 300$ ;
- Phase abruptly increases by nearly 180° and passing 0° at 2450 rad/s; also, the slope of the magnitude changes from -20 dB/decade to 20 dB/decade at 2450 rad/s  $\rightarrow$  there must be a pair of quadratic zeros existing at  $\omega_n=2450$ ;
- Difference in the corner frequency of the asymptotes to the minimal response is 10 dB  $\rightarrow$   $\zeta = 0.16$ .
- Slope of magnitude returns to 0 dB/decade as  $\omega$  exceeds 50000; specifically, magnitude is -3 dB and phase is 45° at 20000 rad/s  $\rightarrow$  there must be a second pole at  $p_2=20000$ .

$$T(s) = \frac{(s/2450)^2 + (0.32/2450)s + 1}{(s/300 + 1)(s/20000 + 1)}$$



#### Performance Specifications in the Frequency Domain


☐ For a second-order system with a pair of complex poles:




☐ For a higher-order system, if the frequency response is **dominated** by a pair of complex poles, the relationship between frequency response and time response will be valid.

### Maximum Magnitude

At the resonant frequency  $\omega_r$  a maximum value  $M_{p\omega}$  of the frequency response is attained.




$$M_{p\omega} = |G(j\omega_r)| = \left(2\zeta\sqrt{1-\zeta^2}\right)^{-1}, \quad \zeta < 0.707.$$




Maximum magnitude  $M_{p\omega} \uparrow \rightarrow$  Damping ratio  $\zeta \downarrow \rightarrow$  Percent Overshoot P.O.  $\uparrow$ 

#### Bandwidth

The bandwidth is the frequency at which the frequency response has declined 3 dB from its low-frequency value.







Bandwidth  $\omega_B \uparrow$  (with a constant  $\zeta$ )  $\rightarrow$  Natural frequency  $\omega_n \uparrow \rightarrow$  Settling time  $T_s \downarrow$ 

### Bandwidth vs. Settling Time

$$T_3(s) = \frac{100}{s^2 + 10s + 100}$$


$$T_4(s) = \frac{900}{s^2 + 30s + 900}$$





### Gain Margin and Phase Margin


- For a closed-loop control system, with loop transfer function  $L(j\omega)$ , the characteristic equation is  $1 + L(j\omega) = 0 \rightarrow L(j\omega) = -1 + j0$ .
- It indicates that when  $|L(j\omega)| = 1$  (or  $20 \log(|L(j\omega)|) = 0$  dB) and  $\angle L(j\omega) = \pm 180^{\circ}$ , the closed-loop system is marginally stable.



- The gain margin GM is the increase in the gain of the  $L(j\omega)$  when phase =  $\pm 180^o$  that will result in a marginally stable system;
- The <u>phase margin</u>  $\emptyset_{pm}$  is the amount of phase shift of the  $L(j\omega)$  at unity magnitude (0 dB) that will result in a marginally stable system.

#### Relative Stability

- $L_1(j\omega)=\frac{1}{j\omega(j\omega+1)(0.2j\omega+1)}$ , phase margin is 43°, gain margin is 15 dB  $L_2(j\omega)=\frac{1}{j\omega(j\omega+1)^2}$ , phase margin is 20°, gain margin is 5.7 dB




#### System 1 is MORE stable than system 2!

-- Gain margin or phase margin is actually a measure of relative stability.

### Phase Margin and Damping Ratio

$$\zeta = 0.01 \phi_{\rm pm}$$
,



Copyright ©2017 Pearson Education, All Rights Reserved

#### Compensator

- The performance of a feedback control system is of primary importance. A suitable control system is stable and result in an acceptable response to input commands, is less sensitive to system parameter changes, results in a minimum steady-state error for input commands, and is able to reduce the effect of undesirable disturbances.
- A feedback control system that provides an optimum performance without any necessary adjustments is rare.
- Thus, the design of a control system is concerned with the arrangement, or the plan, of the system structure and the selection of suitable components and parameters.
- The alteration or adjustment of a control system in order to provide a suitable performance is called compensation.
- A compensator is an additional component that is inserted into a control system to compensate for deficient performance.

### Compensator Structure

$$G_c(s) = \frac{K \prod_{i=1}^{M} (s + z_i)}{\prod_{j=1}^{n} (s + p_j)}$$


Compensator  $G_c(s)$  can be chosen to alter either the shape of the root locus or the frequency response.

Compensator  $G_c(s)$  is used with a process G(s) so that the overall loop gain can be set to satisfy the steady state error requirement, and then  $G_c(s)$  is used to adjust the system dynamics favorably without affecting the steady state error.


First order compensator with the transfer function

$$G_c(s) = \frac{K(s+z)}{(s+p)}$$

#### Phase – Lead Compensator



$$G_{c(j\omega)} = \frac{K(j\omega + z)}{(j\omega + p)} = \frac{K(1 + j\omega\alpha\tau)}{\alpha(1 + j\omega\tau)}$$
$$\tau = \frac{1}{p} \text{ and } \alpha = p/z > 1.$$




The maximum phase lead  $\emptyset_m$  occurs at  $\omega_m$ .


$$\omega_m = \sqrt{zp} = \frac{1}{\tau \sqrt{\alpha}}.$$

$$\sin\phi_m=\frac{\alpha-1}{\alpha+1}.$$

### Phase - Lag Compensator



$$G_{c(j\omega)} = \frac{K(j\omega + z)}{(j\omega + p)} = \frac{K\alpha(1 + j\omega\tau)}{1 + j\omega\alpha\tau}$$
  
 $\tau = \frac{1}{z}$  and  $\alpha = z/p > 1$ .



The maximum phase lag  $\emptyset_m$  occurs at  $\omega_m$ .

$$\omega_m = \sqrt{zp} = \frac{1}{\tau \sqrt{\alpha}}.$$


$$\sin \phi_m = \frac{\alpha - 1}{\alpha + 1}.$$

 $-90^{\circ}$ 

### Example 22.2

Let's consider the below system, we assume  $G(s) = \frac{10}{s^2}$ , and H(s) = 1. It is clear that without compensator, the closed-loop system is marginally stable. Design the compensator to satisfy the following specifications using frequency response methods:

- 1. Settling time (with 2% criterion)  $T_s \leq 4s$ ;
- 2. System damping ratio  $\zeta \geq 0.45$ .



#### **Solutions:**

Step 1.

$$T_s = \frac{4}{\zeta \omega_n} = 4;$$

$$\omega_B = (-1.19\zeta + 1.85)\omega_n = 3.00$$

 $\omega_n = \frac{1}{\zeta} = \frac{1}{0.45} = 2.22.$   $\Rightarrow$  The bandwidth of the closed-loop system should be larger than 3 rad/s.

#### Step 2.

The phase margin of the system is required to be approximately

$$\phi_{\rm pm} = \frac{\zeta}{0.01} = \frac{0.45}{0.01} = 45^{\circ}.$$

The phase margin of the uncompensated system (G(s)) is  $0^o \rightarrow$  The compensator needs to provide a phase-lead angle of at least  $45^o$  to the loop transfer function.

$$\frac{\alpha - 1}{\alpha + 1} = \sin \phi_m = \sin 45^\circ \qquad \qquad \alpha = 5.8$$

We use  $\alpha=6$ . The gain added to the system at the frequency  $\omega_m$  is

$$10 \log \alpha = 7.78 \, \mathrm{dB}$$

We want to have  $\omega_m$  equal to the compensated slope crossing the 0 dB axis, thus, the compensated crossover frequency is located by evaluating the frequency where the uncompensated magnitude curve is equal to -7.78 dB. So,

$$\omega_{m} = 4.95$$

#### Step 3.


We can now determine the pole and zero of the compensator.

$$p = \omega_m \sqrt{\alpha} = 12.0 \qquad z = p/\alpha = 2.0$$

The compensator is

$$G_c(s) = \frac{K}{6} \frac{(1+s/2.0)}{(1+s/12.0)}$$
 Choose K=6 to kee gain being still 10.

Choose K=6 to keep the loop





#### Step 4.

Validate, and re-design if the specifications are not satisfied.


The total loop transfer function is


$$L(s) = \frac{10(1+s/2)}{s^2(1+s/12)} = \frac{60(s+2)}{s^2(s+12)}.$$

The closed-loop transfer function is

$$T(s) = \frac{60(s+2)}{s^3 + 12s^2 + 60s + 120}$$

Obtain the bode plots for T(s) or step response of the system.







$$T_S = 1.3 \text{ s; } P. O. = 34\%;$$
  
 $\omega_B = 8.4 \text{ rad/s}$ 

→ The design specifications have been satisfied.




### Frequency Response using Matlab





```
% Bode plot script for Figure 8.39 % num=5*[0.1 1]; f1=[1 0]; f2=[0.5 1]; f3=[1/2500 .6/50 1]; den=conv(f1,conv(f2,f3)); s(1+0.5s)\left(1+\frac{0.6}{50}s+\frac{1}{50^2}s^2\right) sys=tf(num,den); bode(sys)
```

Convright @2017 Pearson Education, All Rights Reserved



## Thank You!