

Logic Switch with Clock Generator

Author: Marc Lemay Quebec, Canada

email:

MLemay@CollegeShawinigan.qc.ca

APPLICATION OPERATION

The first application of my Logic Switch is to help prototypes of digital circuit. There are two main functions:


1 - Logic Level Generator

The momentary switch acts as a debounced switch. Each time you press the switch the outputs toggle. There are also two led indictors to show the state of the outputs Q and 'Q.

2 - Clock Generator

To enter or exit this mode you need to press the switch at least 2 seconds. The first time you enter this mode the outputs oscillate at 1 Hz. Pressing again will change frequency to 10 Hz (LED L5 On). Pressing a second time for 100 Hz (LED L2 On) and a third time for 1 KHz (LED L1 On). Pressing the switch again will reset frequency to 1 Hz. Note that duty cycle is 50% for all frequencies.

BLOCK DIAGRAM



MICROCHIP HARDWARE DEVELOPMENT TOOLS USED

Assemble/Complier version:

MPlab 3.22, MPasm 1.5

BILL OF MATERIAL

	Part	Description
C1		Ceramic Capacitor 0.1uF 50v
R1-R2 R4	-R6	680 Ohms resistor 1/4 watt
R3		4.7 K Ohms resistor 1/4 watt
L1-L2-L5		Rectangular LED (2mm x 5mm)
L3-L4		Round LED T1 3/4
SW1		Momentary Switch E- Switch #520-03-1
U1		PIC12C508-04/P

Microchip Technology Incorporated, has been granted a nonexclusive, worldwide license to reproduce, publish and distribute all submitted materials, in either original or edited form. The author has affirmed that this work is an original, unpublished work and that he/she owns all rights to such work. All property rights, such as patents, copyrights and trademarks remain with author.

APPENDIX A: SOURCE CODE

```
;*********************
   Marc Lemay
   Electro Technician
   221 St-Isidore
   St-Etienne-des-Gres
   Quebec, Canada
   G0X 2P0
   Tel: (819) 535-4117
   Project: Logic Switch
   date : august 23 1997
; **********************
list p=12c508, f=inhx8m ;uC number
                                          ;and inhx8m output format file
decfreq
           equ 0x07
                      ; low register use for frequency generation
           equ 0x0e
                      ; high register use for frequency generation
decfreqh
freqscale equ 0x08
                      ; low prescale value for frequency generation
fregscaleh equ 0x0f
                      ; high prescale value for frequency generation
                      i1 = 1 \text{ Khz}
                                          ;10 =100 Hz
                                          ;100= 10 Hz
                                          ;1000= 1 Hz
                                                        3e8 hexa
timeswp
          equ 0x09
                      ;switch time pressed
                                          ;each unit = 16 msec
swcourte
           equ 0x0a
                    ;1 = switch pressed detected
                      ;switch prescale 0 to 31 = 16 msec
swprescale equ 0x0b
funct
           equ 0x0c
                      ;0 = 0 logic output (stable)
                                          ;1 = 1 logic output (stable)
               ;2 = output = freq 1 Hz
               ;3 = output = freq 10 Hz
               ;4 = output = freq 100 Hz
               ;5 = output = freq 1 KHz
functtmp
           equ 0x0d
                      ;temp register
           equ 0x06
                      ;adrs io
gpio
tmr0
           equ 0x01;adrs timer
status
           equ 0x03
                    ;status register adrs
osccal
                equ 0x05;oscillator calibration register
                      0000
            ora
       ;begin init
begin
            movwf
                      osccal
                                          ; save oscillator calibration value
                      0x08
                            ;gp0 gp1 gp2 gp4 gp5 output gp3 input
            tris
       movlw 0xd1
                      ;prescale =1/4 for RC internal
            option
            clrf
                   decfregh;
            clrf
                   decfreq ;
            clrf
                      freqscaleh;0 = freq. stop
                      freqscale;0 = freq. stop
            clrf
            clrf
                      timeswp ;time switch pressed = 0
            clrf
                      swcourte
            clrf
                      funct ;function = 0 = ouput = 0
```

```
movlw
                     0 \times 1 f
                             ;31 decimal
             movwf
                     swprescale; init prescale switch pressed to 31
                                              ;logic 0 on gpi0 and 1 on gpi1
             movlw
                                              ;gp2, gp4 et gp5 at 1 log ->led freq. off
             movwf
                         gpio
                         0 \times 05
                                              ;init value for timer0
             movlw
             movwf
                         tmr0
              ;end init
              ;begin master prog
princ
        btfsstmr0,07
                        ;test bit 7 of tmr0
             goto
                         princ
                                              ;wait until tmr0 = 128
              ;each 500 Usec the program will go here
                                              ;init value of tmr0 to 5 to give a good 500 usec
                         0 \times 05
             movlw
                                              ;for time base
             movwf
                         t.mr0
             movf
                     freqscale,0;mov freqscale in w
                         status,2;check the z bit in status
             btfss
                         freqact ;if freqscale <> 0 the freq. is running
             goto
              ; here the freq. is off and a logic 0 or 1 is steady to the output
             btfss
                                              ;test switch pressed=1 log open=0 log.
suite
                         gpio,3
             goto
                         open
             ;goto here if switch pressed ---> gp3 = 1 log.
                         swprescale,1;var decrement from 31 to 0
             goto
                         princ
                                              ;if <> 0 we return to princ
              ;here the switch is pressed since 16 msec
             movlw
                         0x1f
                                              ;value 31 decimal
             movwf
                         swprescale; re-init swprescale to 31
             incf
                                              ;inc value time switch pressed
             btfsc
                         timeswp,2;test if timeswp = 4 (64 msec pressed ?)
             goto
                         rendu4
                                              ;branch if timeswp = 4 (from 4 to 7 it's ok)
             there we check the 2 second switch pressed
             movlw
                         0.8 \times 0
                                              ;w <-- 128
                                                          for 2 sec.
             subwf
                         timeswp,0;compare w and timeswp
             btfss
                         status,2;skip if z bit = 1
             goto
                         princ
                                              ;if z bit = 0 the switch not pressed for 2 second
             ;here the switch is pressed since 2 second
                         fregscale,1; move to affect the z flag
             btfss
                         status,2;skip if z flag is 1
             goto
                         tologic; if z is 0 then freqscale <> 0 then freq is running
              ; here the logic mode is on... we stop it to make a freq. running
             bcf
                         gpio,5
                                              ;led 1 KHz on
             movlw
                         0x05
                                              i5 = 1 \text{ Khz}
                                              ;funct = 5 = 1 KHz
             movwf
                         funct
             movlw
                         0xc8
                                              ;c8 = 200 dec. prescale before output toggle
             movwf
                         fregscale
             movwf
                         decfreq
             clrf
                         freqscaleh
                         decfregh
             clrf
scansw
             btfsc
                         gpio,3
                                              ;test if switch open
                                              ;scan while sw not open
             goto
             movlw
                         0x1f
                                              ;31 decimal
             movwf
                         swprescale; re-init prescale
             clrf
                         timeswp
                                              ;time switch pressed
             goto
                         princ
                                              ;return to princ to scan tmr0
```

```
tologic
                                             ; here the freq. will be stopped and
                                             ;a steady logic 0 will be at the output
             clrf
                        funct
                                             ;function = 0
             clrf
                        freqscale; deactive the frequency
             clrf
                        freqscaleh;
                                             ;output gpi0 = 0
                                                                 gpil (inverse) = 1
             movlw
                        0 \times 36
                                             ; and frequency led OFF
             goto
                        princ
                                             ;return to master program to scan tmr0
rendu4
                                             ; branch here when the switch is pressed for 64 msec
             movlw
             movwf
                        swcourte; init variable swcourte to 1 (the switch is good)
             goto
                        princ
                                            ;reture to master program to scan tmr0
open
                                            ; jump here when the switch in not pressed
             movlw
                      0x1f
                                            ;31 decimal
                      swprescale; re-init prescale for switch
             movwf
             clrf
                       timeswp
                                            reset timeswp because swith is open
             movf
                       swcourte,1;check if swcourte=0
             btfsc
                       status,2;test le z flag si 0 logique
             goto
                        princ
                                             ; branch if z flag equal 1 log.
             ;here swcourte = 1 log. then switch good
                       swcourte; reset swcourteto 0
                                            ;move funct in w register
             movwf
                       functtmp; put a copy of funct in functtmp
             btfsc
                       status,2;check the z flag
                        funct1
                                            ; if z = 1 then branche to funct1
             goto
             decf
                        functtmp,1
             btfsc
                       status,2;check z flag
                                            ; if z = 1 then branch to funct0
             goto
                       funct0
                      functtmp,1
             decf
             btfsc
                       status,2;check z flag
                                            ; if z = 1 then branch to funct3
             goto
                       funct3
             decf
                       functtmp,1
             btfsc
                        status,2;check z flag
                        funct4
                                            ; if z = 1 then branch to funct4
             aoto
             decf
                        functtmp,1
                        status,2;check z flag
             goto
                        funct5
                                             ; if z = 1 then branch to funct5
             ;here the function if 5
                                             ;here the next funct will be 2 --> 1 Hz
             movlw
                        0x02
             movwf
                        funct
                                             ;function = 2 now
             movlw
                        0xe8
                                             ;3e8 = 1000 dec
             movwf
                       freqscale
             movwf
                        decfreq
             movlw
                       0 \times 03
             movwf
                       fregscaleh
             movwf
                       decfregh;
             bsf
                                            ;led 500-1000 Hz off. no led for 1 Hz rate
                        gpio,5
             goto
                        princ
                                             ;return to main program to scan tmr0
funct1
                        ;here the active function will be 1
             incf
                        funct,1
                                            ifunct = 1
                                             ;output = 1 and leds off
             movlw
                        0x35
             movwf
                        gpio
             goto
                        princ
                                             ;return to main program to scan tmr0
funct0
                        ;here the active function will be 0
```

```
clrf
                                             ; funct = 0
                        funct
             movlw
                        0x36
                                             ;output q= 0
                        gpio
             goto
                        princ
                                             ;return to main program to scan tmr0
funct3
                        ;here the active function will be 3 10 Hz
             incf
                                            ;incremente funct --> 3
             movlw
                        0x64
                                             ;64 = 100 dec
             movwf
                        freqscale
             movwf
                        decfreq
             clrf
                        freqscaleh
                        decfregh; reset high byte
             clrf
             bcf
                        gpio,2
                                             ;led 10 Hz on
             goto
                        princ
                                             ;return to main program to scan tmr0
funct4
                        ;here the active function will be 4 100Hz
             incf
                                            ;incremente funct --> 4
             movlw
                        0x0a
                                             ;0a = 10 dec
                        freqscale
             movwf
             movwf
                        decfreq
             clrf
                        fregscaleh
             clrf
                        decfreqh; reset high byte
             bsf
                        gpio,2
                                             ;led 10Hz off
                                             ;led 100 Hz on
             bcf
                        gpio,4
                                             ;return to main program to scan tmr0
                        princ
             goto
funct5
                        ;here the active function will be 5 1000 Hz
             incf
                        funct
                                   ;incremente funct --> 5
             movlw
                        0 \times 01
                                             ;01 = 1 dec = 1 KHz
             movwf
                        fregscale
                        decfreq
             movwf
             clrf
                        freqscaleh
             clrf
                        decfreqh; reset high byte
                                             ;led 100 Hz off
             bsf
                        apio,4
             bcf
                        gpio,5
                                             ;led 1000 Hz on
             goto
                        princ
                                             ;return to main program to scan tmr0
freqact
                                             ; here frequency mode is active
             decf
                        decfreq,1;decremente decfreq
             btfss
                        status,2;test z flag
                                             ; branche if z <> 0
             goto
                        suite
             movf
                        decfreqh,0;check high byte if = 0
                        status,2;check z flag
             btfss
             goto
                        decfreqhigh;branch if > 0
             ;here we toggle the output
                                             ; load w with gpio : clock out
             movf
                        gpio,0
             xorlw
                        0x03
                                             ;2 last bits to toggle
             movwf
                        gpio
             movf
                        freqscale,0;freqscale --> w
             movwf
                        decfreq
                                             ;re-init decfreq for next toggle
                        freqscaleh,0
             movf
                        decfreqh; init byte high
             movwf
             goto
                        suite
decfreqhigh
             decf
                        decfreqh,1;decremente byte high
                        suite
             goto
             end
```

NOTES: