

Bill Of Ma	Top sid	• /	Coulhought	onent BOM numb	
Line#	Designator	Comment	? Quantity		
1	C1, C3, C5, C6, C7, C8	100nF		N 4	
3	C101, C201	27pF	- Comportent BO	ılyı numb	
4	C102, C103, C104, C105, C106, C107, C108, C109, C110, C111, C112, C113, C202, C203, C204, C205, C206, C207, C208, C209, C210, C211, C212, C213	10uF	24		
5	D1, D3, D101, D102, D112, D201, D202, D212	SS16	8		
6	D2	SMAJ24A	1		
7	D4, D5	1SMA5918BT			
8	D103, D104, D105, D106, D107, D108, D109, D203, D204, D205, D206, D207, D208, D209	SMBJ150A			
9	D110, D210	SMBJ150C			
10	D111, D211	BAS416	2		
11	IC1	LM2596R-A[OJ 1		
12	IC2, IC3	FOD3182SD)V 2		
13	IC4	PC817	1		
17	L1	33uH	1		
21	R1	20k	1		
22	R2	2k	1		
23	R3	1k8	1		
24	R4, R5, R6, R7, R9, R10, R11, R12	1k	8		
25	R8, R13, R14, R15	4k7	4		
26	R16, R18	2k	2		
27	R17, R103, R104, R105, R106, R107, R108, R109, R110, R203, R204, R205, R206, R207, R208, R209, R210	150k 17			
28	R19	100k	1		
29	R101, R201	20	2		
30	R102, R202	120k	2		
32	R112, R212	10k	2		
33	R113, R213	6k8	2		
34	T1	BC817	1		
35	TP1, TP2, TP3, TP4, TP5, TP6, TP7, TP8, TP9, TP10, TP11, TP12, TP13, TP14, TP15, TP16, TP17, TP18, TP19, TP101, TP102, TP103, TP104, TP105, TP106, TP107, TP201, TP202, TP203, TP204, TP205, TP206, TP207	Test_point			

Bottom side


Bill Of Materials


	Biii Of Materials					
_	Line #	Designator	Comment	Quantity		
	2	C2, C4	220uF	2		
	14	J1		1		
	15	J2, J3, J5		3		
	16	J4		1		
	18	LD1	Yellow	1		
	19	LD2	Red	1		
	20	M1	2SC0115T	1		
	31	R111, R114, R211, R214	5R6	4-		

─ 31 !!! R111, R114, R211, R214 is won't install !!!


Project: IGBT Gate Driver 15A


Mail: avxusi@gmail.com





BOM number: 5, 6, 7, 8, 11, 12, 13 components all is additionally glued from the bottom





Project: IGBT Gate Driver 15A

Mail: avxusi@gmail.com