## Milliken Recommended Carpet Maintenance Procedures

Consistent, thorough cleaning is required to remove soil that has bonded to carpet fibers. To ensure optimum performance and appearance, Milliken recommends using the MilliCare Dry Carpet Cleaning system.



MilliCare Textile and Carpet Care® is Green Seal Certified and an IICRC Certified training provider. The proprietary dry care system is CRI Certified as a Deep Cleaning Methodology and can contribute to LEED points. To find a MilliCare service provider in your area, please visit www.millicare.com.

## **Prevention Procedures**

**Barrier Mats** - Barrier mats should be placed at all entrance ways into the facility and at locations were there is a transition from hard surface flooring onto the carpet if possible. This will help prevent soil from being tracked onto the carpet, improving its appearance and extending its life. Barrier mats should be vacuumed daily and cleaned or replaced frequently depending on the weather and use.

**Vacuuming** - Proper vacuuming is one of the most important parts of a total preventive maintenance program. Ineffective equipment or procedures will accelerate the appearance loss of the carpet by allowing dirt and grit to penetrate the pile surface. The accumulation of this soil, especially the smaller respirable particulates, can lead to Indoor Air Quality problems.

The janitorial / housekeeping staff is typically assigned the task of scheduled vacuuming. Vacuuming frequencies should be determined by four factors:

- 1. Type of carpet installed and appearance expectations.
- 2. Type and quality of vacuum used.
- 3. Expected traffic for each area of the facility.
- 4. Soiling environment of each area of the facility.

A commercial upright vacuum with a beater brush is recommended for vacuuming all carpet. Regular maintenance of vacuums is also essential. Vacuums should be emptied and inspected after every use. Particular attention should be paid to the condition of the brushes. Also, make sure that there is no material obstructing the air-flow channel.

Typical vacuuming frequencies are as follows:

High traffic: Every full work day. All entrances, exits, lobbies, food service areas, main corridors, elevators, funnel and pivot points. The vacuum should make a minimum of three passes in all high traffic areas.

Medium traffic: Every other work day. All secondary corridors, conference rooms, private offices.

Low traffic: Once a week. Minimal use corridors, rarely used conference rooms and training rooms.

## Milliken Recommended Carpet Maintenance Procedures (Cont.)

**Spot Cleaning** - Spots and stains are one of the biggest detriments to high appearance levels. In order to maintain a consistent appearance level between periodic maintenance, it's critical that spots and stains be removed on a daily basis. In most cases, daily spotting is the responsibility of the janitorial or housekeeping staff. Milliken recommends the use of a Capture® Spot Kit or MilliCare® Spot Kit for treating most spots, following these procedures:

- 1. Remove as much excess material as possible prior to spot removal. Blot up liquids with a clean white terry cloth, vacuum up soil and gently scrap up encrusted material.
- 2. Spray Capture Pre-mist onto a clean, white terry towel and work in gently. Do not scrub. Blot, absorbing as much of the spot into the towel as possible. Work from the outside edge of the spot into the center to prevent spreading.
- 3. Apply Capture dry carpet cleaner to the spot. Gently agitate with a brush, wait 30 mins. And vacuum.

Note: Milliken does not recommend using any spotting agents containing solvents as they can leave residue that contributes to resoiling and can possibly damage the carpet.