

Antenna Factor

$$AF = 20 \cdot \log \left(\frac{9.73}{\lambda \sqrt{G_{(num)}}} \right)$$

$$Gain_{(num)} = \left(\frac{9.73}{\lambda 10^{AF/20}} \right)^2$$

<https://www.ahsystems.com/notes/How-to-use-antenna-factors.php>

<https://www.ahsystems.com/EMC-formulas-equations/Antenna-Factor-Gain-calculation.php>

<https://www.ahsystems.com/articles/Antenna-Factor-Calculations.php>

- its the ratio between field strength and voltage input or vice versa for receiving
- it depends on frequency/wavelength
- Unit of dB/m