

Resistor tolerance when manufactured on IC is very bad like 20%, so whenever the circuit example in the course shows a resistor, it is most likely performed by some other crazier circuit

Golden Current Reference

Also in actual IC design, the first current reference made using band gap reference circuit, the for resistor is to show only

DC Gate Biasing

people.engr.tamu.edu/spalermo/ecen474/lecture17_ee474_fully_diff_amps_cmfb.pdf

- its called common mode feedback, CMFB
 - it samples output midpoint to feedback to give the correct VOD