

1. Write design equation in terms of V_{OV} since that is a hyper parameter for design, since V_{OV} location is chosen based on supply rails
2. Write design equation in terms of g_m/C since that relates to f_T and will appear a lot expressions