


Potentiometer control servo

1. Learning target

In this course, we will earn how to use Micro:bit, 16-channels servo debugging board and potentiometer module to control servo.

2. Preparation

Connect the module to Micro:bit board by expansion board, as shown below.



3. Programming method

Mode 1 online programming: First, we need to connect the micro:bit to the computer by USB cable. The computer will pop up a USB flash drive and click on the URL in the USB flash drive: http://microbit.org/ to enter the programming interface. Add the Yahboom package https://github.com/YahboomTechnology/Servo 16C to programming.


Mode 2 offline programming: We need to open the offline programming software. After the installation is complete, enter the programming interface, click 【New Project】, add Yahboom package: https://github.com/YahboomTechnology/Servo_16C, you can start programming.

4.Looking for blocks


The following is the location of the building blocks required for this programming.
















5.Combine block

The summary program is shown below.



```
set num v to num v + v 1

if num v to 4

set num v to num v to 4

set num v to num v to 1

if num v to 1

set servo si v angle map Potentiometer pin P0 v from low 0 high 1023 to low 0 high 180 by iic clse if num v v v 3 then clse if num v v v 3 then clse if num v v v 4 then clse if num v v v 4 then clse if num v v v 4 then clse if num v v v v angle map Potentiometer pin P0 v from low 0 high 1023 to low 0 high 180 by iic clse if num v v v v angle map Potentiometer pin P0 v from low 0 high 1023 to low 0 high 180 by iic clse if num v v v v angle map Potentiometer pin P0 v from low 0 high 1023 to low 0 high 180 by iic clse if num v v v v angle map Potentiometer pin P0 v from low 0 high 1023 to low 0 high 180 by iic
```

6. Phenomenon

After the program is downloaded successfully. Twist the potentiometer, servo S1 will turn. Press the micro:bit button A, the dot matrix screen will display 2. Twist the potentiometer, servo S2 will turn. Press the micro:bit button B, the dot matrix will display 1. Twist the potentiometer, servo S2 will turn.