JetCam Usage

JetCam Usage
- 1. JetCam Installation
- 2. JetCam Usage
  - USB Camera
- References

JetCam is an easy-to-use Python library developed by NVIDIA for the Jetson platform for integrating and operating USB cameras or CSI cameras. CSI cameras require an adapter board and are currently unavailable.

1. JetCam Installation

The factory image already has the driver installed; please skip the installation steps.

```
git clone https://github.com/NVIDIA-AI-IOT/jetcam
```

```
cd jetcam
```

```
sudo python3 setup.py install
```

```
sudo pip3 install ipywidgets
```



2. JetCam Usage

JetCam provides typical sample programs to demonstrate how to use a USB camera.

This example requires Jupyter Lab to run. Using our factory image system, you can directly access it via the motherboard IP:8888!

USB Camera

In Jupyter Lab, navigate to the folder containing the USB camera and open the file. The factory image system folder path is:

```
/home/jetson/jetcam/notebooks/usb_camera
```



References

https://github.com/NVIDIA-AI-IOT/jetcam