GPIO Read Function

GPIO Read Function
1. GPIO Pin Diagram
2. Running the Program
3. Program Results

1. GPIO Pin Diagram

GPIO.BOARD pin 12 corresponds to GPIO.BCM pin 18:



2. Running the Program

```
cd ~/jetson-gpio/samples
```

```
export JETSON_MODEL_NAME=JETSON_AGX_ORIN
```

```
python3 simple_input.py
```

3. Program Results

Use DuPont wires to connect GPIO.BOARD pin 12 to the GND and 3.3V pins on the motherboard to test the high and low level reading:

Caution: Do not connect incorrectly or cause a short circuit. Errors may damage the motherboard hardware!