1. Astra camera calibration

1、Astra camera calibration

1.1 Preparation before calibration

1.2 calibration

1.2.1 Color icon set

1.2.2 Depth image calibration

Wiki: http://wiki.ros.org/camera calibration

Official website link: https://orbbec3d.com/develop/

Astra camera: https://github.com/orbbec/ros astra camera

Due to the internal and external reasons of the camera, the image will be greatly distorted, mainly radial deformation and tangential deformation, which cause the straight line to become curved. The farther the pixel is from the center of the image, the more serious the distortion. In order to avoid errors caused by the data source, it is necessary to calibrate the parameters of the camera.

Disadvantages of infrared depth camera ranging:

- (1) It is impossible to accurately measure the distance of a black object, because the black substance can absorb infrared rays, and the infrared rays cannot return, so the distance measurement cannot be performed.
- (2) It is impossible to accurately measure the distance of the mirror-reflecting object, because only when the depth camera is on the vertical line of the mirror-surface object, the receiver can receive the reflected infrared rays, and it will cause overexposure.
- (3) It is impossible to accurately measure the distance of transparent objects, because infrared rays can pass through transparent objects.
- (4) It is impossible to accurately measure the distance of objects that are too close.

Astra Series



Product Name	ASTRA PRO	ASTRA S	ASTRA	
Range	0.6m - 8m	0.4m - 2m	0.6m - 8m	
FOV	60°H x 49.5°V x 73°D			
RGB Image Res.	1280 x 720 @30fps	640 x 480 @30fps	640 x 480 @30fps	
Depth Image Res.	640 x 480 @30fps			
Size	165mm x 30mm x 40mm			
Temperature	0 – 40°C			
Power Supply	USB 2.0			
Power Consumption	< 2.4 W			
Operating Systems	Android/Linux/Windows 7/8/10			
SDK	Astra SDK or OpenNI			
Microphones	2 (Built – in)			

1.1. Preparation before calibration


• You need a <u>checkerboard</u>. This tutorial uses a 9x6 checkerboard and a 20mm square, which should be flattened during calibration.

The calibration uses the internal vertex of the checkerboard, so the "10x7" checkerboard uses the internal vertex parameter "9x6", as shown in the example below.

The calibration board of any specification can be used, just change the parameters.

- An open area without obstacles and calibration board patterns
- Monocular camera that publishes images via ROS

Checkerboard (calibration board)



7×10 | Size: 20mm

Obi Zhongguang camera model and corresponding launch file

Launch file	Start the camera model
astra.launch	Astra, Astra S, Astra mini, Astra mini S
astraplus.launch	Astra plus
astraproplus.launch	Astra pro plus
embedded_s.launch	Deeyea
dabai_u3.launch	Dabai
gemini.launch	Gemini

Device view

_			
_ 7	CI	10	h
	Dι	ıs	IJ

```
jetson@yahboom:~$ lsusb
Bus 002 Device 004: ID 0781:5583 SanDisk Corp.
Bus 002 Device 003: ID 2109:0817 VIA Labs, Inc.
Bus 002 Device 002: ID 2109:0817 VIA Labs, Inc.
Bus 002 Device 001: ID 1d6b:0003 Linux Foundation 3.0 root hub
Bus 001 Device 003: ID 8087:0a2b Intel Corp.
Bus 001 Device 010: ID 2bc5:050f
Bus 001 Device 007: ID 2bc5:060f
Bus 001 Device 006: ID 05e3:0608 Genesys Logic, Inc. Hub
Bus 001 Device 011: ID 2109:8817 VIA Labs, Inc.
Bus 001 Device 009: ID 1a86:7523 QinHeng Electronics HL-340 USB-Serial adapter
Bus 001 Device 008: ID 10c4:ea60 Cygnal Integrated Products, Inc. CP210x UART Br
idge / myAVR mySmartUSB light
Bus 001 Device 015: ID 17ef:608c Lenovo
Bus 001 Device 014: ID 17ef:608d Lenovo
Bus 001 Device 013: ID 214b:7250
Bus 001 Device 005: ID 2109:2817 VIA Labs, Inc.
Bus 001 Device 012: ID 0079:181c DragonRise Inc.
Bus 001 Device 002: ID 2109:2817 VIA Labs, Inc.
Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
```

The appearance of these two IDs indicates that the device is connected.

1.2, calibration

Satrt up Astra camera

```
roslaunch astra_camera astraproplus.launch
```

View picture topic

```
rostopic list
```

```
camera/rgb/camera_info
/camera/rgb/image_raw
/camera/rgb/image_raw/compressed
/camera/rgb/image_raw/compressed/parameter_descriptions
/camera/rgb/image_raw/compressed/parameter_updates
/camera/rgb/image_raw/compressedDepth
/camera/rgb/image_raw/compressedDepth/parameter_descriptions/camera/rgb/image_raw/compressedDepth/parameter_updates
/camera/rgb/image_raw/theora
/camera/rgb/image_raw/theora/parameter_descriptions
/camera/rgb/image_raw/theora/parameter_updates
/camera/rgb/image_rect_color
/camera/rgb/image_rect_color/compressed
/camera/rgb/image_rect_color/compressed/parameter_descriptions
/camera/rgb/image_rect_color/compressed/parameter_updates
/camera/rgb/image_rect_color/compressedDepth
/camera/rgb/image_rect_color/compressedDepth/parameter_descriptions
/camera/rgb/image_rect_color/compressedDepth/parameter_updates
/camera/rgb/image_rect_color/theora
/camera/rgb/image_rect_color/theora/parameter_descriptions
/camera/rgb/image_rect_color/theora/parameter_updates
/camera/rgb_rectify_color/parameter_descriptions
/camera/rgb_rectify_color/parameter_updates
rosout
 rosout_agg
/tf_static
```

Start the calibration node

```
# Color map
rosrun camera_calibration cameracalibrator.py image:=/camera/rgb/image_raw
camera:=/camera/rgb --size 9x6 --square 0.02
```

size: The number of internal corners of the calibrated checkerboard, such as 9X6, the corners have six rows and nine columns.

square: The side length of the checkerboard, in meters.

image and camera: Set the topic of the image released by the camera.

1.2.1、Color icon set



Calibration interface


X: The left and right movement of the checkerboard in the camera field of view

Y: The checkerboard moves up and down in the camera's field of view


Size: the back and forth movement of the checkerboard in the camera's field of view

Skew: The tilt and rotation of the checkerboard in the camera field of view

After the startup is successful, put the checkerboard into the center of the screen and change different poses. The system will recognize it autonomously. In the best case, the lines under [X], [Y], [Size], and [Skew] will first change from red to yellow and then to green as the data is collected, filling them as much as possible.



Click [CALIBRATE] to calculate the camera internal parameters, the more pictures, the longer the time, just wait.



Click [SAVE] to save the uncalibrated result, the bottom line appears, click [COMMIT] to exit.

```
[-0.07028213194362816, 0.00043818252903837866, -0.01245084517224107, 0.000404835
0406427093, 0.0]

K = [543.8333273852593, 0.0, 344.1989291964055, 0.0, 544.5128476949725, 219.77155460
oST version 5.0 parameters
image]
vidth
neight
narrow_stereo]
543.833327 0.000000 344.198929
0.000000 544.512848 219.771555
0.000000 0.000000 1.000000
0.070282 0.000438 -0.012451 0.000405 0.000000
1.000000 0.000000 0.000000
0.000000 1.000000 0.000000
0.000000 0.000000 1.000000
projection
30.847900 0.000000 345.778233 0.000000
.000000 534.555359 214.989044 0.000000
0.000000 0.000000 1.000000 0.000000
 'Wrote calibration data to', '/tmp/calibrationdata.tar.gz')
```

After the calibration, the calibration result is stored in [/tmp/calibrationdata.tar.gz], you can move it out to see the content

```
sudo mv /tmp/calibrationdata.tar.gz ~
```

After decompression, there are the image just calibrated, an ost.txt file and an ost.yaml file. The yaml file is what we need, but it needs to be modified before it can be used.

- -Change ost.yaml to head_camera.yaml
- -Change the name of camera_name: to head_camera
- -Move the file to ~/.ros/camera_info folder

1.2.2. Depth image calibration

Start the calibration node

```
rosrun camera_calibration cameracalibrator.py image:=/camera/ir/image camera:=/camera/ir --size 9x6 --square 0.02
```


size: The number of internal corners of the calibrated checkerboard, such as 9X6, the corners have six rows and nine columns.

square: The side length of the checkerboard, in meters.

image and camera: Set the topic of the image released by the camera.

The calibration process is similar to color camera calibration, but the visualization of depth camera calibration is not so intuitive; it just displays the calibration result when it is recognized, and it is completely dark when it is not recognized.

rqt_image_view



The following operations are similar to color camera calibration, changing different poses. The system will recognize it autonomously. In the best case, the lines under [X], [Y], [Size], and [Skew] will first change from red to yellow and then to green as the data is collected, filling them as much as possible. Click [CALIBRATE] to calculate the camera internal parameters, the more pictures, the longer the time, just wait.

Click [SAVE] to save the non-calibration result, the bottom line appears, click [COMMIT] to exit. After the calibration, the calibration result is stored in [/tmp/calibrationdata.tar.gz], you can move it out to see the content.

sudo mv /tmp/calibrationdata.tar.gz ~

After decompression, there are the image just calibrated, an ost.txt file and an ost.yaml file. The yaml file is what we need, but it needs to be modified before it can be used.

- Change ost.yaml to depth_Astra_Orbbec.yaml
- Change the name behind camera_name: to depth_Astra_Orbbec
- Move the file to ~/.ros/camera_info folder