Manage JupyterLab service

In the factory image, the Jupyter Lab service will be automatically started when the computer is turned on. Under normal circumstances, it does not need to be managed, just keep it started automatically when the computer is turned on.

Shut down the service

Shut down the program service

sudo systemctl stop yahboom_jupyterlab.service

Permanently shut down the service

sudo systemctl disable yahboom_jupyterlab.service

Query the service status

sudo systemctl status yahboom_jupyterlab.service

Enable the service

Start the service

sudo systemctl start yahboom_jupyterlab.service

Restart the service

sudo systemctl restart yahboom_jupyterlab.service

Set the service to start automatically at boot

sudo systemctl enable yahboom_jupyterlab.service