

Manage JupyterLab Services

In the factory image, Jupyter Lab service will automatically start at boot. Under normal circumstances, no management is needed; just keep it set to auto-start at boot.

Close Services

Stop program service

```
sudo systemctl stop jupyterlab.service
```

Permanently close service

```
sudo systemctl disable jupyterlab.service
```

Query service status

```
sudo systemctl status jupyterlab.service
```

Start Services

Start service

```
sudo systemctl start jupyterlab.service
```

Restart service

```
sudo systemctl restart jupyterlab.service
```

Set service to auto-start at boot

```
sudo systemctl enable jupyterlab.service
```