

# Color Block Tracking and Grasping

Before starting this function, you need to close the main program and APP processes. If you need to restart the main program and APP later, start them from the terminal:

```
bash ~/dofbot_pro/APP_DOFBOT_PRO/start_app.sh
```

## 1. Function Description

After the program starts, it recognizes color blocks and tracks them, making the color block center coincide with the image center. After the robotic arm is stationary for 2-3 seconds, if the depth distance is valid (not 0), the buzzer will sound once, and the robotic arm will adjust its posture to grasp the color block. After grasping, it places it at the designated position, then returns to the color block recognition posture.

## 2. Startup and Operation


### 2.1. Startup Commands

Enter the following commands in the terminal to start:

```
# Start camera:  
ros2 launch orbbec_camera dabai_dcw2.launch.py  
# Start low-level control:  
ros2 run dofbot_pro_driver arm_driver  
# Start inverse kinematics program:  
ros2 run dofbot_pro_info kinematics_dofbot  
# Start color block tracking and grasping program:  
ros2 run dofbot_pro_color color_follow
```


### 2.2. Operation

After the program starts, hold a 4cm\*4cm color block in front of the camera. Use the mouse to select a part of the color block area to obtain the HSV value of the color block. The program starts recognizing the color block. The robotic arm will adjust its posture to make the color block center coincide with the image center. Slowly move the color block, and the robotic arm will follow the color block movement, continuously adjusting its posture. After the color block center coincides with the image center, if the depth information in the upper left corner of the image is not 0 and the distance from the color block to the base is less than 30cm, it means the color block center coordinate depth value is valid and within the robotic arm's grasping range. The buzzer will sound once, and the robotic arm will adjust its posture to grasp the color block based on its position. After grasping, it places it at the designated position and finally returns to the recognition posture. If the robotic arm cannot meet the conditions (depth information not 0 and distance less than 30cm, greater than 18cm), you need to move the color block back and forth again to make it stationary after tracking to meet the grasping conditions.



### 3. Program Flowchart

color\_follow.py



### 4. Core Code Analysis

Code path:

```
/home/jetson/dofbot_pro_ws/src/dofbot_pro_color/dofbot_pro_color/color_follow.py
```

Import necessary libraries:

```

import cv2
import rclpy
from rclpy.node import Node
import numpy as np
from message_filters import ApproximateTimeSynchronizer, Subscriber
from sensor_msgs.msg import Image
from std_msgs.msg import Float32, Bool
from cv_bridge import CvBridge
import cv2 as cv

encoding = ['16UC1', '32FC1']
import time
import math
import os
#color recognition
  
```

```

from dofbot_pro_color.astra_common import *
from dofbot_pro_interface.msg import *
from dofbot_pro_color.Dofbot_Track import *
import tf_transformations as tf
import transforms3d as tfs

```

Program parameter initialization, create publishers, subscribers, etc.:

```

def __init__(self):
    super().__init__('color_detect')
    self.declare_param()
    self.window_name = "depth_image"
    self.init_joints = [90.0, 150.0, 12.0, 20.0, 90.0, 30.0]
    self.dofbot_tracker = DofbotTrack()
    self.cx = 0
    self.cy = 0
    self.pubPoint = self.create_publisher(ArmJoint, "TargetAngle", 1)
    self.grasp_status_sub = self.create_subscription(Bool, 'grab',
self.grabStatusCallback, 1)

    self.depth_image_sub = Subscriber(self, Image, "/camera/color/image_raw",
qos_profile=1)
    self.rgb_image_sub = Subscriber(self, Image, "/camera/depth/image_raw",
qos_profile=1)
    self.TimeSynchronizer = ApproximateTimeSynchronizer([self.depth_image_sub,
self.rgb_image_sub],queue_size=10,slop=0.5)
    self.TimeSynchronizer.registerCallback(self.TrackAndGrap)
    #Count variable, used to record the number of times conditions are met
    self.cnt = 0
    #Create bridges for converting color and depth image topic message data to
image data
    self.rgb_bridge = CvBridge()
    self.depth_bridge = CvBridge()
    #color
    #Initialize area coordinates
    self.Roi_init = ()
    #Initialize HSV values
    self.hsv_range = ()
    #Initialize recognized color block information, here representing color block
center x coordinate, center y coordinate and minimum enclosing circle radius r
    self.circle = (0, 0, 0)
    #Dynamic parameter adjustment flag, True means perform dynamic parameter
adjustment
    self.dyn_update = True
    #Mouse selection flag
    self.select_flags = False
    self.gTracker_state = False
    self.windows_name = 'frame'
    self.Track_state = 'init'
    #Create color detection object
    self.color = color_detect()
    #Initialize area coordinates row and column coordinates
    self.cols, self.rows = 0, 0
    #Initialize mouse selected xy coordinates
    self.Mouse_XY = (0, 0)
    #Store color block center value coordinates xy
    self.cx = 0

```

```

self.cy = 0
#Default HSV threshold file path, this file stores last saved HSV values
self.hsv_text = rospkg.RosPack().get_path("dofbot_pro_color") +
"/scripts/colorHSV.text"
Server(ColorHSVConfig, self.dynamic_reconfigure_callback)
self.dyn_client = Client(nodeName, timeout=60)
#Minimum enclosing circle radius of color block after image processing
self.circle_r = 0
#Current depth value of color block center coordinates
self.cur_distance = 0.0
#Corner coordinates xy, used to calculate servo 5 value
self.corner_x = self.corner_y = 0.0
exit_code = os.system('rosservice call /camera/set_color_exposure 50')

```

Focus on the TrackAndGrap callback function:

```

def TrackAndGrap(self,color_frame,depth_frame):
    #Receive color image topic message, convert message data to image data
    rgb_image = self.rgb_bridge.imgmsg_to_cv2(color_frame, 'bgr8')
    result_image = np.copy(rgb_image)
    #Receive depth image topic message, convert message data to image data
    depth_image = self.depth_bridge.imgmsg_to_cv2(depth_frame, encoding[1])
    frame = cv.resize(depth_image, (640, 480))
    depth_image_info = frame.astype(np.float32)
    action = cv.waitKey(10) & 0xFF
    result_image = cv.resize(result_image, (640, 480))
    #Pass the obtained color image as parameter to process, and also pass
    keyboard event action
    result_frame, binary = self.process(result_image,action)
    #Check if stored color block center value coordinates xy are not 0 and color
    block minimum enclosing circle radius is greater than 30
    if self.cx!=0 and self.cy!=0 and self.circle_r>30 :
        #Check if stored color block center value coordinates xy are within
        valid range
        if self.cx<=640 or self.cy <=480:
            center_x, center_y = self.cx,self.cy
            #Calculate depth value of color block center point
            self.cur_distance =
            depth_image_info[int(center_y),int(center_x)]/1000.0
            print("self.cur_distance: ",self.cur_distance)
            dist = round(self.cur_distance,3)
            dist = 'dist: ' + str(dist) + 'm'
            #Draw center point depth value on color image
            cv.putText(result_frame, dist, (30, 30), cv.FONT_HERSHEY_SIMPLEX,
            1.0, (255, 0, 0), 2)
            #If color block center point coordinates differ from image center
            point (320, 240) by more than 10, meaning not within acceptable range, execute
            tracking program to adjust robotic arm state to bring color block center value
            within acceptable range
            if abs(center_x-320) >10 or abs(center_y-240)>10:
                #Execute tracking program, input is current color block center
                value
                self.dofbot_tracker.XY_track(center_x,center_y)
                #If color block center point coordinates differ from image center
                point (320, 240) by less than 10, can be considered that color block center value
                is in the middle of the image
                else:

```

```

        #Under satisfying conditions, accumulate self.cnt
        self.cnt = self.cnt + 1
        #When accumulated count reaches 50, it means color block center
        value is stationary in the middle of the image
        if self.cnt==50:
            #Clear self.cnt count
            self.cnt = 0
            print("take it now!")
            #Check if current depth value is 0, non-zero means the value
is valid
            if self.cur_distance!=0:
                #Calculate servo 5 value through corner coordinates
                angle_radians = math.atan2(self.corner_y, self.corner_x)
                angle_degrees = math.degrees(angle_radians)
                print("angle_degrees: ",angle_degrees)
                if abs(angle_degrees) >90:
                    compute_angle = abs(angle_degrees) - 45
                else:
                    compute_angle = abs(angle_degrees)
                print("compute_angle: ",compute_angle)
                self.dofbot_tracker.set_joint5 = compute_angle
                #Execute grasping program, calling the clamping function
                #of the created dofbot_tracker object, input parameters are color block center
                value and center point depth value

                self.dofbot_tracker.clamping(center_x,center_y,self.cur_distance)

        #Check if binary image exists, if so display color and binary images,
        otherwise only display color image
        if len(binary) != 0: cv.imshow(self.windows_name, ManyImgs(1,
([result_frame, binary])))
        else:
            cv.imshow(self.windows_name, result_frame)

```

Image processing function self.process:

```

def process(self, rgb_img, action):
    rgb_img = cv.resize(rgb_img, (640, 480))
    binary = []
    #Check key event, when i or I is pressed, change state to recognition mode
    if action == ord('i') or action == ord('I'): self.Track_state = "identify"
    #Check key event, when r or R is pressed, reset all parameters, enter color
    selection mode
    elif action == ord('r') or action == ord('R'): self.Reset()
    #Check state value, if init, means initial state value, can use mouse to
    select area at this time
    if self.Track_state == 'init':
        #Select an area color within the specified window
        cv.namedWindow(self.windows_name, cv.WINDOW_AUTOSIZE)
        cv.setMouseCallback(self.windows_name, self.onMouse, 0)
        #Check color selection flag, true means can select color
        if self.select_flags == True:
            cv.line(rgb_img, self.cols, self.rows, (255, 0, 0), 2)
            cv.rectangle(rgb_img, self.cols, self.rows, (0, 255, 0), 2)
            #Check if selected area exists
            if self.Roi_init[0] != self.Roi_init[2] and self.Roi_init[1] !=
self.Roi_init[3]:

```

```

        #Call Roi_hsv function in created color detection object
self.color, returns processed color image and HSV values
        rgb_img, self.hsv_range = self.color.Roi_hsv(rgb_img,
self.Roi_init)
            self.gTracker_state = True
            self.dyn_update = True
        else: self.Track_state = 'init'
#Check state value, if "identify", means can perform color recognition

elif self.Track_state == "identify":
    #Check if HSV threshold file exists, if so read values and assign to
hsv_range
        if os.path.exists(self.hsv_text): self.hsv_range =
read_HSV(self.hsv_text)
            #If not exists, change state to init for color selection
            else: self.Track_state = 'init'
        if self.Track_state != 'init':
            #Check self.hsv_range value length, meaning check if this value exists,
when length is not 0, enter color detection function
            if len(self.hsv_range) != 0:
                #Call object_follow function in created color detection object
self.color, pass color image and self.hsv_range (hsv threshold), returns
processed color image, binary image and information about graphics meeting hsv
threshold, including center point coordinates and its minimum enclosing circle
radius
                rgb_img, binary, self.circle ,corners=
self.color.object_follow(rgb_img, self.hsv_range)
                    print("corners[0]: ",corners[0][0])
                    print("corners[0]: ",corners[0][1])
                    self.corner_x = int(corners[0][0]) - int(self.circle[0])
                    self.corner_y = int(corners[0][1]) - int(self.circle[1])
                    #Assign return values to stored center values self.cx and self.cy,
minimum enclosing circle radius assigned to self.circle_r
                    self.cx = self.circle[0]
                    self.cy = self.circle[1]
                    self.circle_r = self.circle[2]
                    #Check dynamic parameter update flag, True means can update hsv_text
file and modify values on parameter server
                    if self.dyn_update == True:
                        write_HSV(self.hsv_text, self.hsv_range)
                        params = {'Hmin': self.hsv_range[0][0], 'Hmax':
self.hsv_range[1][0],
                                'Smin': self.hsv_range[0][1], 'Smax':
self.hsv_range[1][1],
                                'Vmin': self.hsv_range[0][2], 'Vmax':
self.hsv_range[1][2]}
                        self.dyn_client.update_configuration(params)
                        self.dyn_update = False

return rgb_img, binary

```

Let's look at the implementation process of the Clamping function of the created dofbot\_tracker object. This function is located in the Dofbot\_Track library, Dofbot\_Track library location /home/jetson/dofbot\_pro\_ws/src/dofbot\_pro\_color/scripts/Dofbot\_Track.py

```

def Clamping(self,cx,cy,cz):
    #Get current robotic arm end position and pose

```

```

        self.get_current_end_pos(self.cur_joints)
        #Start coordinate system conversion, finally get color block center
coordinates position in world coordinate system
        camera_location = self.pixel_to_camera_depth((cx,cy),cz)
        PoseEndMat = np.matmul(self.EndToCamMat,
self.xyz_euler_to_mat(camera_location, (0, 0, 0)))
        EndPointMat = self.get_end_point_mat()
        WorldPose = np.matmul(EndPointMat, PoseEndMat)
        pose_T, pose_R = self.mat_to_xyz_euler(worldPose)
        #Add offset parameters to compensate for deviations caused by servo value
differences
        pose_T[0] = pose_T[0] + self.x_offset
        pose_T[1] = pose_T[1] + self.y_offset
        pose_T[2] = pose_T[2] + self.z_offset
        #Call inverse kinematics IK algorithm, input parameter is pose_T obtained
through coordinate system conversion, which is color block center coordinates
position in world coordinate system, calculate 6 servo values through IK
        #Call inverse kinematics service, calling ik service content, assign required
request parameters
        request = kinematicsRequest()
        #Target x value of robotic arm end, unit is m
        request.tar_x = pose_T[0]
        #Target y value of robotic arm end, unit is m
        request.tar_y = pose_T[1]
        #Target z value of robotic arm end, unit is m, 0.2 is scaling factor, make
minor adjustments based on actual situation
        request.tar_z = pose_T[2]
        #Specify service content as ik
        request.kin_name = "ik"
        #Target Roll value of robotic arm end, unit is radians, this value is current
robotic arm end roll value
        request.Roll = self.CurEndPos[3]
        print("calcutate_request: ",request)
try:
    response = self.client.call(request)
    joints = [0.0, 0.0, 0.0, 0.0, 0.0, 0.0]
    #Assign service returned joint1-joint6 values to joints
    joints[0] = response.joint1 #response.joint1
    joints[1] = response.joint2
    joints[2] = response.joint3
    if response.joint4>90:
        joints[3] = 90
    else:
        joints[3] = response.joint4
    joints[4] = 90
    joints[5] = 20
    #Calculate distance from color block to robotic arm base coordinate
system
    dist = math.sqrt(request.tar_y ** 2 + request.tar_x** 2)
    #If distance is between 18cm and 30cm, control robotic arm to move to
grasping point
    if dist>0.18 and dist<0.30:
        self.Buzzer()
        print("compute_joints: ",joints)
        #Execute pubTargetArm function, pass calculated joints values as
parameters
        self.pub_arm(joints)
        #Execute grasping action and movement, placement actions

```

```
    self.move()
else:
    print("It's too far to catch it!Please move it forward a bit. ")
except Exception:
    rospy.loginfo("run error")
```