## 16. Contour detection

## 16.1、Use

Source code launch file path: ~/jetcobot\_ws/src/opencv\_apps/launch

Step 1: Start the camera

roslaunch jetcobot\_visual opencv\_apps.launch img\_flip:=false

• img\_flip parameters: Whether the image needs to be flipped horizontally, the default is false.

Step 2: Start the corner detection function of Opencv\_apps

roslaunch opencv\_apps find\_contours.launch

# Contour detection

Each functional case will have a parameter [debug\_view], Boolean type, whether to use Opencv to display images, which is displayed by default.

If no display is required, set it to [False], for example

roslaunch opencv\_apps contour\_moments.launch debug\_view:=False

However, after starting in this way, some cases cannot be displayed in other ways, because in the source code, some [debug\_view] is set to [False], which will turn off image processing.

## 16.2、Display method

rqt\_image\_view

Enter the following command to select the corresponding topic

rqt\_image\_view

opencv

The system displays it by default and no processing is required.

## 16.3、Effect display

You can drag the slider to view the outline of the screen.

