#### 10.Contour moment

Moment functions are widely used in image analysis, such as pattern recognition, target classification, target recognition and orientation estimation, image encoding and reconstruction, etc. The moment set calculated from an image can not only describe the global characteristics of the image shape, but also provide a large amount of different geometric feature information about the image, such as size, position, direction and shape. The description ability of image moments is widely used in target recognition and orientation estimation in various fields of image processing, computer vision and robotics.

First moment: related to shape;

Second moment: shows how much the curve extends around the mean of the straight line;

Third-order moment: a symmetry measurement about the mean value; 7 invariant moments can be derived from the second-order moment and the third-order moment. The invariant moment is a statistical characteristic of the image, which satisfies the invariance of translation, expansion and contraction, and rotation, and is widely used in the field of image recognition.

## 10.1、Use

Source code launch file path: ~/jetcobot\_ws/src/opencv\_apps/launch

Step 1: Start the camera

roslaunch jetcobot\_visual opencv\_apps.launch img\_flip:=false

• img\_flip parameter: whether the image needs to be flipped horizontally, the default is false. Step 2: Start the corner detection function of Opencv\_apps

```
roslaunch opencv_apps contour_moments.launch
```

# Contour moment

Each functional case will have a parameter [debug\_view], Boolean type, whether to use Opencv to display images, which is displayed by default.

If no display is required, set it to [False], for example

```
roslaunch opencv_apps contour_moments.launch debug_view:=False
```

However, after starting in this way, some cases cannot be displayed in other ways, because in the source code, some [debug\_view] is set to [False], which will turn off image processing.

### 10.2. Display method

• rqt\_image\_view

Enter the following command to select the corresponding topic

```
rqt_image_view
```

opencv

The system displays it by default and no processing is required.

# 10.3、Effect display

Contour moments use parameters. There will be a topic for subscribing images and publishing images.

Parameter	Туре	Default	Analyze
~use_camera_info	bool	true	Subscribe to the topic [camera_info] to get the default coordinate system ID, otherwise use the image information directly.
~debug_view	bool	false	Whether to create a window to display the node image
~canny_low_threshold	int	0	Canny edge detection low threshold
~queue_size	int	3	Queue size

#### Effect picture.

