

Control RGB Light

1. API Introduction

The API for RGB light:

Arm_RGB_set(R, G, B)

Function: Set the color of the RGB light.

Parameters:

R: Controls the brightness of red color for the RGB light, range 0-255, higher value means brighter.

G: Controls the brightness of green color for the RGB light, range 0-255, higher value means brighter.

B: Controls the brightness of blue color for the RGB light, range 0-255, higher value means brighter.

Return value: None.

2. Code Content

Code path: /home/yahboom/Dofbot/3.ctrl_Arm/1.rgb.ipynb

```
# Loop to make the RGB light on the DOFBOT expansion board glow red, green, blue.
#!/usr/bin/env python3
#coding=utf-8
import time
from Arm_Lib import Arm_Device
# Get DOFBOT object
Arm = Arm_Device()
time.sleep(.1)
def main():
    while True:
        Arm.Arm_RGB_set(50, 0, 0) # RGB lights up red
        time.sleep(.5)
        Arm.Arm_RGB_set(0, 50, 0) # RGB lights up green
        time.sleep(.5)
        Arm.Arm_RGB_set(0, 0, 50) # RGB lights up blue
        time.sleep(.5)
        print(" END OF LINE! ")
try :
    main()
except KeyboardInterrupt:
    # Release Arm object
    del Arm
    print(" Program closed! ")
    pass
```

Open the 1.rgb.ipynb file from jupyter lab, and click the "Run All" button on the jupyter lab toolbar to see the RGB light on the DOFBOT expansion board cycle through red, green, and blue colors every 0.5 seconds.



To exit, click the Stop button on the toolbar.

