## [Precautions]

1. Login user and password related content:

Username: pi Password: yahboom

Vnc remote login password: yahboom

Jupyterlab login password: yahboom

Factory hotspot signal: DOGZILLA\_WIFI Password: 12345678

- 2. If the robot dog is found lying on the ground, it means the battery is low, please charge the robot dog in time. The charging interface of the robot dog is at the bottom, connect the input end of the charger to the power supply, and plug the output end of the charger into the charging interface of the robot dog to charge.
- 3. Since plugging in the charger will force the output to turn off, the Raspberry Pi will automatically power off and shut down. Before charging, please save the data of the Raspberry Pi, and then insert the charger to avoid data loss due to forced shutdown.
- 4. Before running the singleton program, please close the APP program that is started at startup, otherwise it may cause influence.
- 5. The carrying capacity of the robot dog is limited, please do not add any heavy objects to the robot dog.
- 6. The robot dog APP requires the mobile phone and the robot dog to be connected to the same local area network. The mobile phone needs to be connected to the robot dog's hotspot or the mobile phone and the robot dog are connected to the same router.

## **(Specifications for batteries )**

- 1. It is strictly forbidden to connect to equipment that exceeds the product's use load.
- 2. It is strictly forbidden to use batteries or chargers not officially provided by YAHBOOM.
- 3. When the battery level is less than 9, the robot dog will lie on the ground, and power switch indicator breathing light effect. At this time, the robot dog cannot be controlled. Please turn off the power and charge the robot dog in time.
- 4. Please turn off the power switch when charging the robot dog. For safety reasons, the robot dog will be forced to turn off the power output when charging, and the robot dog cannot be used at this time.
- 5. When the battery is charging, the indicator light of the charger will turn on red, and when fully charged, it will turn on green. After the charging is completed, the charger should be unplugged in time to avoid overcharging and damaging the battery. Someone needs to be present when charging.
- 6. Turn off the power switch of the robot dog after use. When the device is not used for a long time, it is recommended to charge the robot dog to about 80% first, and check the battery power at regular intervals to avoid over-discharge.
- 7. Keep away from heat, fire, any liquid, never use in damp or rain. A humid environment may cause short-circuit damage to the product.
- 8. When the battery or battery charger catches fire or smoke, please use sand or dry powder fire extinguisher to put out the fire, and then quickly evacuate to a safe area.

- 9. If the battery or battery charger is damaged, seriously heated, deformed, discolored, smelly or any other abnormal phenomenon, please do not use it, and contact YAHBOOM or other agents to deal with it in time.
- 10. Please use it in an environment with a temperature of 0°C to 35°C. The stability of the battery or battery charger may decrease at other temperatures.
- 11. It is strictly forbidden to intentionally puncture, short-circuit, reverse connection, privately weld, impact, crush, throw the battery or battery charger.
- 12. It is forbidden to use the product in the environment of strong static electricity and strong magnetic field, otherwise it will cause damage to the product.
- 13. It is strictly forbidden to refit or modify the hardware circuit board without permission.
- 14. When there is no adult supervision, please do not let children use the battery or battery charger, and store the battery in a place where children can't get it.
- 15. If the battery or battery charger is smoking or hot (in severe cases, the casing will crack), you should quickly disconnect the main power switch, the power strip or the main switch, and put the product in an open area.