## 5.AR QR code

The Raspberry Pi motherboard does not currently support running this function on the motherboard, but the image data can be transmitted to the virtual machine through distributed communication, and the virtual machine can track and identify it. The premise is that the motherboard and the virtual machine need to set up distributed communication, refer to the previous tutorial to set up.

#### 2.1 Overview

ARTag (AR tag, AR means "augmented reality") is a benchmark marking system that can be understood as a reference for other objects. It looks similar to a QR code, but its encoding system is still very different from a QR code. It is mostly used in camera calibration, robot positioning, augmented reality (AR) and other applications. One of the most important functions is to identify the position relationship between the object and the camera. ARTag can be attached to the object, or ARTag label can be attached to the plane to calibrate the camera. After the camera recognizes the ARTag, it can calculate the position and attitude of the tag in the camera coordinates.

ar track alvar has 4 main functions:

- Generate AR tags with different sizes, resolutions and data/ID encodings.
- Recognize and track poses of individual AR tags, optionally integrating kinect depth data (when kinect is available) for better pose estimation.
- Recognize and track poses in "bundles" consisting of multiple tags. This allows for more stable pose estimation, robustness to occlusions, and tracking of multilateral objects.
- Automatically calculate spatial relationships between tags in bundles using camera images so users don't have to manually measure and enter tag locations in an XML file to use the bundle feature.

Alvar is newer and more advanced than ARToolkit, which has been the basis for several other ROS AR tag packages. Alvar features adaptive thresholding to handle various lighting conditions, optical flow-based tracking for more stable pose estimation, and an improved tag recognition method that does not slow down significantly as the number of tags increases.

## 2.2 Create AR QR code

• Continuously generate multiple tags on one image

roscore
rosrun ar\_track\_alvar createMarker

```
Description:
 This is an example of how to use the 'MarkerData' and 'MarkerArtoolkit'
 classes to generate marker images. This application can be used to
 generate markers and multimarker setups that can be used with
 SampleMarkerDetector and SampleMultiMarker.
Usage:
 /opt/ros/melodic/lib/ar_track_alvar/createMarker [options] argument
                     marker with number 65535
   65535
                     force hamming(8,4) encoding
   -f 65535
   -1 "hello world"
                     marker with string
                     marker with file reference
   -2 catalog.xml
                     marker with URL
   -3 www.vtt.fi
                     use units corresponding to 1.0 unit per 96 pixels
   -u 96
                     use inches as units (assuming 96 dpi)
   -uin
                     use cm's as units (assuming 96 dpi) <default>
   -ucm
                     use marker size 5.0x5.0 units (default 9.0x9.0)
   -s 5.0
                     marker content resolution -- 0 uses default
   -m 2.0
                     marker margin resolution -- 0 uses default
                     use ArToolkit style matrix markers
   - a
   - p
                     prompt marker placements interactively from the user
Prompt marker placements interactively
 units: 1 cm 0.393701 inches
 marker side: 9 units
 marker id (use -1 to end) [0]:
```

You can enter [ID] and location information here, and enter [-1] to end. One or more can be generated, and the layout can be designed by yourself.

```
rompt marker placements interactively
 units: 1 cm 0.393701 inches
 marker side: 9 units
 marker id (use -1 to end) [0]: 0
 x position (in current units) [0]: 0
 y position (in current units) [0]: 0
ADDING MARKER 0
 marker id (use -1 to end) [1]: 1
 x position (in current units) [18]: 0
 y position (in current units) [0]: 10
ADDING MARKER 1
 marker id (use -1 to end) [2]: 2
 x position (in current units) [18]: 10
 y position (in current units) [0]: 0
ADDING MARKER 2
 marker id (use -1 to end) [3]: 3
 x position (in current units) [10]: 10
 y position (in current units) [18]: 10
ADDING MARKER 3
 marker id (use -1 to end) [4]: -1
Saving: MarkerData_0_1_2_3.png
Saving: MarkerData 0 1 2 3.xml
```

 Generate a single number: command + parameters directly generate a digital picture; for example

```
rosrun ar_track_alvar createMarker 11
rosrun ar_track_alvar createMarker -s 5 33
```

11: The number is the QR code of 11. -s: Specify image size. 5: 5x5 picture. 33: The number is the QR code of 33.

The files generated by the above two generation methods are stored in the terminal directory of the running command.

# 2.3 ARTag identification


Raspberry Pi motherboard startup method is as follows:

#Establishing multi-machine communication between Raspberry Pi and virtual machine, and taking Raspberry Pi as the host as an example roslaunch usb\_cam usb\_cam-test.launch #Start the Raspberry Pi and drive the USB camera roslaunch dofbot\_visual ar\_track.launch open\_rviz:=true #Start the virtual machine, identify and track

Jetson-nano and the virtual machine are started as follows,

roslaunch dofbot\_visual ar\_track.launch open\_rviz:=true

• The open\_rviz parameter is open by default



In rviz, you need to set the corresponding camera topic name.

- Image\_Topic: The camera topic is [/usb\_cam/image\_raw].
- Marker: The display component of rviz. Different squares display the location of the AR QR code.
- TF: The display component of rviz, used to display the coordinate system of AR QR codes.
- Camera: The display component of rviz, which displays the camera screen.
- world: world coordinate system.
- usb\_cam: camera coordinate system.

# 2.4 ar\_track\_alvar node

### Subscribed topics:

话题名	数据类型
/camera_info	(sensor msgs/CameraInfo)
/image_raw	(sensor_msgs/Image)

### Topics posted:

话题名	数据类型
/visualization_marker	(visualization msgs/Marker)
/ar_pose_marker	(ar track alvar/AlvarMarkers)

# 2.5 View the node diagram

Terminal input,

