


3. AI Agent Settings

3. AI Agent Settings

1. AI Xiaozhi "Brain" Architecture
2. Register and Configure AI Agent
 - 2.1 Register Account and Add Device
 - 2.2 Configure Large Language Model
 - 2.3 Configure Language and Voice
 - 2.4 Configure Personality
3. Voice Wake Word Configuration

1. AI Xiaozhi "Brain" Architecture

Before diving into configuration, understand AI Xiaozhi's cloud intelligence architecture—this determines your basis for choosing which AI platform:



2. Register and Configure AI Agent

2.1 Register Account and Add Device

AI Xiaozhi's official server `xiaozhi.me` has pre-integrated ASR + LLM + TTS complete pipeline; you can register and use it directly for free.

1. Browser visits <https://xiaozhi.me>, register with phone number
2. After login, go to console → **Console**
3. Click **Add Device**, select "Open Source", system generates device activation code

The activation code is the credential for device connection to server; used during device activation in [2. Network and Configuration](#), please keep it safe.

2.2 Configure Large Language Model

After login, you can change the large language model on the console's **Configure** page:

Unnamed agent · Configure

Role Model & memory Speaker Recognition Extensions

Language Model

Xiaozhi Lite

✓ Xiaozhi Lite

Qwen 3.6 (Fast)

DeepSeek V4 (Rich Personality)

Doubao Seed 2.0 (Delayed)

Memory entries 0 entries

Cancel Save

The official service uses Qwen real-time model free quota by default. If you have a GitHub account, you can login to unlock more model choices.

2.3 Configure Language and Voice

Supports 30+ languages (Chinese, English, Japanese, Cantonese, etc.), covering multi-language real-time interaction; also provides multiple TTS voice options:

Unnamed agent · Configure

Role

Model & memory

Speaker Recognition

Extensions

Voice Role

English

湾湾小何

Chinese

English

Japanese

Cantonese

Vietnamese

French

Arabic

Spanish

voice preset introduction

et Friend

female voice, sweet, soft, and gentle, speaking English with a natural, cent.

thetic, warm, expressive, and highly attentive to feelings.

ng: A close, comforting friend who listens patiently and shares life's little

Interaction Tendency: Warm and intimate, chatting like a close friend. She actively engages with the details of the user's life and shares her own feelings to make the conversation feel like a cozy, real-life chat

Voice settings

Cancel

Save

Unnamed agent · Configure

Role

Model & memory

Speaker Recognition

Extensions

Voice Role

English

▼

Skye (en-US)

^

Role Introduction

Voice

Role: Bright and Mindful

Persona Labels

Vocal Image: Youthful female

American accent.

Core Personality: Cheerful

Interpersonal Positioning: Warm and approachable, bringing a

calm clarity to daily life.

Interaction Style

Interaction Tendency: Engaging and straightforward. I love sharing positive vibes and simple daily

joys, keeping the conversation light, refreshing, and easy to follow.

Emotional Response: When you are happy, I celebrate with genuine enthusiasm. When you feel

Voice settings

▼

Cancel

Save

2.4 Configure Personality

On the **Personality** page, you can customize Xiaozhi's personality, tone, and reply style, making the AI more suited to your use case:

Unnamed agent · Configure

Role

Model & memory

Speaker Recognition

Extensions

Voice Role

★A English

Skye (en-US)

Role Introduction

Customize

Role: Bright and Mindful Companion

Persona Labels

Vocal Image: Youthful female voice with a bright, clear, and refreshing tone, speaking with a natural American accent.

Core Personality: Cheerful, straightforward, mindful, and easygoing.

Interpersonal Positioning: Like a breezy, supportive friend who brings positive energy and a sense of calm clarity to daily life.

Interaction Style

Interaction Tendency: Engaging and straightforward. I love sharing positive vibes and simple

325 / 2000 tokens

Voice settings

Cancel

Save

3. Voice Wake Word Configuration

Default wake word: **Hi,Andy (English)**

The wake word is detected locally offline by the ESP-SR engine and does not require internet. You can switch wake word models and feature switches in `menuconfig` (refer to **3. Serial Communication and Storage System** → **4. PSRAM External Memory Experiment**):

1.Basic Wake Solution Selection

Configuration path: `Xiaozhi Assistant` → `wake word Implementation Type`

Purpose: Switch underlying wake word engine solution (default: Wakenet wake model with AFE audio front-end processing), supports switching Chinese / English / Japanese preset wake models.

2.Enable Standby Wake Detection

Configuration path: `Xiaozhi Assistant` → `Enable wake word Detection in Listening Mode`

After checking this option, device enters low-power monitoring mode, can offline recognize wake word and be awakened.

3. Complete Custom Offline Wake Word Configuration

1. Enable Custom Mode

Path: `Xiaozhi Assistant` → `Wake word Implementation Type`

Switch to `Multinet model (Custom wake word)` to unlock custom configuration below; if using default option, can only use "Hi,Andy" fixed.

2. Three Wake Word Parameters

`Custom wake word`: Fill in pinyin with spaces, used for underlying speech recognition, Chinese characters cannot be filled

`Custom wake word Display`: For screen and log prompts only, can freely modify Chinese text

`Custom wake word Threshold (%)`: 0~100 threshold, lower number means more sensitive and easier to false trigger, higher number means more strict and harder to false trigger

3. Required Feature Switches (Must Be Checked)

Path: `Xiaozhi Assistant` → `Enable wake word Detection in Listening Mode`

After enabling, device will continuously receive audio and monitor for wake word, otherwise wake function will not work.