
## System and desktop introduction

1. Turn on the computer and connect the display screen, and the following figure will be displayed



2. Open the terminal, enter the following command to view the system version information, and then click [INFO] at the bottom to switch to information.

jtop

Jetson Orin NX/Orin Nano version system information

