Version configuration description

Jetcobot robot arm has three main control board versions. Different main control boards have different accessories. The following [List of Items] is common to the three versions.

	Robotic arm		Chassis box
	Adaptive gripper		Acrylic front cover
	OLED expansion board		Chassis box back plate
	Camera module		Robotic arm bottom plate
	Jetcobot USB adapter board		Suction cup
	Camera cable		Power adapter (12V)
	Elbow Type-c data cable		Accessory package
	Instruction manual		Screwdriver
	Gamepad + AAA battery		Map

	30×30mm Block*8 (Red / blue green / yellow)		

The following are the accessories corresponding to the three main control boards.

Jetson Orin Nano board accessories (Optional)

	Jetson Orin Nano board		256GB SSD
	Network card antenna		Power adapter (19V)
	DP to HDMI adapter cable (1.5m)		

Jetson Orin NX board accessories (Optional)

	Jetson Orin NX board		256GB SSD
	Network card antenna		Power adapter (19V)
	DP to HDMI adapter cable (1.5m)		

Jetson Nano board accessories (Optional)

	Jetson Nano B01 board		U Disk
	Nano 4GB accessory package		4010 fan
	HDMI cable		M.2 network card + network card antenna
	Power adapter (5V)		